


2008 ZZR® 600

PARTS DIAGRAM

Air Cleaner

E1130



2008 ZZR® 600

PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,6X25 (Ref # 130)	130H0625	6
BOLT-FLANGED,6X45 (Ref # 130B)	130H0645	3
SCREW-PAN-CROSS,5X20 (Ref # 220)	220D0520	8
FILTER-ASSY-AIR (Ref # 11010)	11010-1736	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-1274	1
GASKET,AIR FILTER (Ref # 11060)	11060-1845	1
GASKET,AIR FILTER (Ref # 11060A)	11060-1846	1
GASKET,CARBURETOR (Ref # 11060B)	11060-1847	4
HOLDER,AIR FILTER ELEMENT (Ref # 13280)	13280-1072	2
HOLDER,AIR FILTER (Ref # 13280A)	13280-1203	1
SCREEN,AIR FILTER (Ref # 14037)	14037-1193	1
DUCT,#1 (Ref # 14073)	14073-1715	2
DUCT,#2 (Ref # 14073A)	14073-1716	2
VALVE,AIR SWITCH (Ref # 16126)	16126-1361	1
SILENCER-INTAKE (Ref # 39162)	39162-1091	1
FITTING,TUBE,T-TYPE (Ref # 92005)	92005-1017	1
FITTING (Ref # 92005C)	92005-1309	1
CLAMP (Ref # 92037)	92037-1712	2
TUBE,FUEL,4X9X140 (Ref # 92059)	92059-1230	1
PLUG (Ref # 92066)	92066-1389	2
CLAMP (Ref # 92170)	92170-1060	3
CLAMP (Ref # 92171)	92171-1230	1
TUBE,AIR FILTER-VALVE (Ref # 92190)	92190-1581	2
TUBE,AIR FILTER-SWITCH (Ref # 92191)	92191-1230	1
TUBE,BLOWBY (Ref # 92191A)	92191-1242	1
TUBE (Ref # 92191B)	92191-1262	2