

# 2004 KFX 250 Mojave


## PARTS DIAGRAM

Valve(s)

**Kawasaki**

Let the Good Times Roll®

E1210



# 2004 KFX 250 Mojave

## PARTS LIST

### Valve(s)

| ITEM NAME                                | PART NUMBER | QUANTITY |
|------------------------------------------|-------------|----------|
| GASKET,14X18X1.5 (Ref # 11009)           | 11009-1430  | 1        |
| VALVE-INTAKE (Ref # 12004)               | 12004-1119  | 2        |
| VALVE-EXHAUST (Ref # 12005)              | 12005-1052  | 2        |
| RETAINER-VALVE SPRING (Ref # 12009)      | 12009-1054  | 4        |
| COLLET (Ref # 12011)                     | 12011-1003  | 8        |
| ARM-ROCKER,INTAKE (Ref # 12016)          | 12016-1071  | 1        |
| ARM-ROCKER,EXHAUST (Ref # 12016A)        | 12016-1083  | 1        |
| SHAFT-ROCKER,INTAKE (Ref # 12020)        | 12020-1055  | 1        |
| SHAFT-ROCKER,EXHAUST (Ref # 12020A)      | 12020-1056  | 1        |
| SEAT-SPRING,12.1X16.2X0.5 (Ref # 16007)  | 16007-1177  | 4        |
| SEAT-SPRING,17.5X23.8X0.5 (Ref # 16007A) | 16007-1178  | 4        |
| SPRING-ENGINE VALVE,INNER (Ref # 49078)  | 49078-1051  | 4        |
| SPRING-ENGINE VALVE,OUTER (Ref # 49078A) | 49078-1056  | 4        |
| SCREW,7MM (Ref # 92009)                  | 92009-1279  | 4        |
| NUT,7MM (Ref # 92015)                    | 92015-1325  | 4        |
| SEAL-OIL,RVC2-5.5X8.5X8.3 (Ref # 92049)  | 92049-1062  | 4        |
| SPRING,ROCKER ARM (Ref # 92081)          | 92081-1740  | 2        |