


2004 KFX400 PARTS DIAGRAM

Crankshaft/Piston(s)

E1320



2004 KFX400 PARTS LIST

Crankshaft/Piston(s)

ITEM NAME	PART NUMBER	QUANTITY
SPROCKET,CAM CHAIN (Ref # 12046)	12046-S005	1
PISTON-ENGINE (Ref # 13001)	13001-S006	1
PIN-PISTON (Ref # 13002)	13002-S006	1
RING-SET-PISTON (Ref # 13008)	13008-S008	1
CRANKSHAFT-COMP (Ref # 13031)	13031-S006	1
ROD-CONNECTING (Ref # 13032)	13032-S007	1
BEARING-BIG END (Ref # 13034)	13034-S006	1
PIN-CRANK (Ref # 13035)	13035-S006	1
CRANKSHAFT,RH (Ref # 13037)	13037-S011	1
CRANKSHAFT,LH (Ref # 13037A)	13037-S012	1
GEAR-PRIMARY SPUR (Ref # 13097)	13097-S005	1
RETAINER (Ref # 14020)	14020-S009	1
GEAR,CRANK BALANCER (Ref # 16085)	16085-S004	1
RING-SNAP,PISTON PIN (Ref # 92033)	92033-S040	2
KEY,PRIMARY DRIVE GEAR (Ref # 92038)	92038-S006	1
PIN,5X8 (Ref # 92043)	92043-S008	1
BEARING-BALL,CRANKSHAFT (Ref # 92045)	92045-S054	2
SEAL-OIL,CRANKSHAFT,RH (Ref # 92049)	92049-S048	1
SCREW (Ref # 92172)	92172-S166	1
WASHER (Ref # 92200)	92200-S140	1
NUT,PRIMARY DRIVE GEAR (Ref # 92210)	92210-S102	1