

2006 KFX50 PARTS LIST

Knuckle Arm

| ITEM NAME | PART NUMBER | QUANTITY |
|---|-------------|----------|
| PIN-HAIR,COTTER (Ref # 39092) | 39092-S005 | 1 |
| ROD-TIE,STEERING (Ref # 39111) | 39111-S002 | 1 |
| RODEND-TIE,RH (Ref # 39112) | 39112-S001 | 1 |
| RODEND-TIE,LH (Ref # 39112A) | 39112-S002 | 1 |
| KNUCKLE,RH (Ref # 39186) | 39186-S001 | 1 |
| KNUCKLE,LH (Ref # 39186A) | 39186-S002 | 1 |
| SPACER (Ref # 92026) | 92026-S060 | 1 |
| SEAL,KNUCKLE ARM DUST (Ref # 92093) | 92093-S017 | 1 |
| BUSHING (Ref # 92139) | 92139-S013 | 1 |
| BOLT,KNUCKLE ARM (Ref # 92153) | 92153-S202 | 1 |
| WASHER,STEERING SHAFT,LWR (Ref # 92200) | 92200-S096 | 1 |
| WASHER,ROD-END (Ref # 92200A) | 92200-S097 | 1 |
| NUT (Ref # 92210) | 92210-S036 | 1 |
| NUT,STEERING SHAFT (Ref # 92210A) | 92210-S071 | 1 |
| NUT,TIE-ROD (Ref # 92210B) | 92210-S072 | 1 |
| NUT,TIE-ROD (Ref # 92210C) | 92210-S073 | 1 |