


# 2003 Prairie 650 4X4

## PARTS DIAGRAM

### Ignition Switch



# 2003 Prairie 650 4X4

## PARTS LIST

### Ignition Switch

| ITEM NAME                              | PART NUMBER | QUANTITY |
|--|-------------|----------|
| SWITCH-COMP,D.C.TERMINAL (Ref # 13151) | 13151-1094  | 1        |
| COVER,KEY (Ref # 14024)                | 14024-1551  | 4        |
| SWITCH-ASSY-IGNITION (Ref # 27005)     | 27005-1267  | 1        |
| KEY-LOCK,BLANK (Ref # 27008)           | 27008-1041  | 1        |
| KEY-LOCK,BLANK (Ref # 27008A)          | 27008-1042  | 1        |
| KEY-LOCK,BLANK (Ref # 27008B)          | 27008-1043  | 1        |
| KEY-LOCK,BLANK (Ref # 27008C)          | 27008-1044  | 1        |
| KEY-LOCK,BLANK (Ref # 27008D)          | 27008-1132  | 1        |
| KEY-LOCK,BLANK (Ref # 27008E)          | 27008-1133  | 1        |
| KEY-LOCK,BLANK (Ref # 27008F)          | 27008-1134  | 1        |
| KEY-LOCK,BLANK (Ref # 27008G)          | 27008-1135  | 1        |
| SWITCH,INVERT SENSOR (Ref # 27010)     | 27010-1421  | 1        |
| SCREW,4X20 (Ref # 92009)               | 92009-1897  | 2        |
| NUT,IGNITION SWITCH (Ref # 92210)      | 92210-1109  | 1        |