

Swingarm

Let the Good Times Roll®

Exploded view diagram of a vehicle chassis assembly. The diagram shows the main chassis frame (33001) and various suspension and steering components. A "FRONT" arrow points to the left. The components and their part numbers are as follows:

- 33032 (Steering knuckle arm)
- 11012 (Washers)
- 42036 (Bushing)
- 92046 (Bushing)
- 92210 (Nut)
- 11012 (Washers)
- 42036 (Bushing)
- 92046 (Bushing)
- 33001 (Main chassis frame)
- 12053B (Lower control arm bracket)
- 92172 (Bushing)
- 92143 (Washer)
- 92143 (Washer)
- 92172 (Bushing)
- 132 (Bushing)
- 221 (Bushing)
- 13272 (Bushing)
- 12053 (Lower control arm bracket)
- 12053A (Lower control arm bracket)
- 92009 (Bushing)
- 13270 (Bushing)
- 92001 (Bushing)
- 92015 (Bushing)
- 33040 (Bushing)

2018 KX™ 85

PARTS LIST

Swingarm

ITEM NAME	PART NUMBER	QUANTITY
CAP (Ref # 11012)	11012-1263	4
GUIDE-CHAIN,RR,LH (Ref # 12053)	12053-0209	1
GUIDE-CHAIN,RR,RH (Ref # 12053A)	12053-0210	1
GUIDE-CHAIN,FR (Ref # 12053B)	12053-1414	1
BOLT-FLANGED-SMALL,6X50 (Ref # 132)	132BA0650	2
PLATE (Ref # 13270)	13270-1899	2
PLATE,GUIDE CHAIN (Ref # 13272)	13272-1446	1
SCREW-CSK-CROS,6X45 (Ref # 221)	221AA0645	2
ARM-COMP-SWING (Ref # 33001)	33001-0610	1
SHAFT-SWING ARM (Ref # 33032)	33032-1161	1
ADJUSTER-CHAIN (Ref # 33040)	33040-0039	2
SLEEVE,SWING ARM,L=34 (Ref # 42036)	42036-1067	2
BOLT,8X46 (Ref # 92001)	92001-1179	2
SCREW,5X10 (Ref # 92009)	92009-1828	4
NUT,FLANGED,8MM (Ref # 92015)	92015-1014	2
BEARING-NEEDLE (Ref # 92046)	92046-1046	2
COLLAR (Ref # 92143)	92143-1676	4
SCREW,5X8 (Ref # 92172)	92172-0119	4
NUT,LOCK,12MM (Ref # 92210)	92210-1249	1