


2008 KFX®50 PARTS DIAGRAM

Crankcase

E1411



2008 KFX®50 PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
GASKET,CRANK CASE (Ref # 11061)	11061-Y002	1
GASKET,CLUTCH COVER (Ref # 11061A)	11061-Y006	1
GEAR-COMP,KICK DRIVEN (Ref # 13216)	13216-Y001	1
COVER-CLUTCH,BLACK (Ref # 14032)	14032-Y001-931	1
CRANKCASE,RH (Ref # 14080)	14080-Y002	1
CRANKCASE,LH (Ref # 14080A)	14080-Y004	1
SHAFT-IDLER,KICK (Ref # 39115)	39115-Y001	1
GEAR-SPUR,KICK STARTER (Ref # 59051)	59051-Y001	1
STUD,7X168 (Ref # 92004)	92004-Y001	2
STUD,7X176 (Ref # 92004A)	92004-Y003	2
RING-SNAP (Ref # 92033)	92033-Y012	1
PIN,8X14 (Ref # 92043)	92043-Y012	4
BEARING-BALL,6201 (Ref # 92045)	92045-Y002	1
BEARING-BALL,6203 (Ref # 92045A)	92045-Y003	1
BEARING-BALL,6203 (Ref # 92045B)	92045-Y006	1
SEAL-OIL,19.8X30X5 (Ref # 92049)	92049-Y001	1
SEAL-OIL,17X30X6 (Ref # 92049A)	92049-Y006	1
PLUG,DRAIN (Ref # 92066)	92066-Y003	1
PLUG (Ref # 92066A)	92066-Y004	1
PLUG (Ref # 92066B)	92066-Y006	1
BUSHING-RUBBER (Ref # 92092)	92092-Y002	1
BUSHING (Ref # 92139)	92139-Y001	1
BUSHING (Ref # 92139A)	92139-Y002	2
SPRING (Ref # 92145)	92145-Y001	1
SPRING,KICK DRIVEN GEAR (Ref # 92145A)	92145-Y011	1
COLLAR (Ref # 92152)	92152-Y006	1
BOLT,FLANGE,8X12 (Ref # 92153)	92153-Y001	2
BOLT,FLANGE,8X40 (Ref # 92153A)	92153-Y035	5
BOLT,FLANGE,8X35 (Ref # 92153B)	92153-Y039	2

2008 KFX®50 PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
BOLT,FLANGE,6X12 (Ref # 92153C)	92153-Y046	1
BOLT,FLANGE,6X35 (Ref # 92153D)	92153-Y053	8
BOLT,FLANGE,6X45 (Ref # 92153E)	92153-Y054	1
WASHER,10MM (Ref # 92200)	92200-Y002	1
WASHER (Ref # 92200A)	92200-Y008	1
WASHER,8MM (Ref # 92200B)	92200-Y010	1