


2009 KFX[®] 90

PARTS DIAGRAM

Crankcase

E1411



2009 KFX[®] 90

PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
GASKET,CRANK CASE (Ref # 11061)	11061-Y003	1
GASKET,CLUTCH COVER (Ref # 11061A)	11061-Y007	1
GEAR-COMP,KICK DRIVEN (Ref # 13216)	13216-Y002	1
PLATE (Ref # 13271)	13271-Y002	1
COVER-CLUTCH,BLACK (Ref # 14032)	14032-Y002-931	1
CRANKCASE,RH (Ref # 14080)	14080-Y001	1
CRANKCASE,LH (Ref # 14080A)	14080-Y003	1
SHAFT-IDLER,KICK (Ref # 39115)	39115-Y001	1
GEAR-SPUR,KICK STARTER (Ref # 59051)	59051-Y001	1
STUD,8X182.5 (Ref # 92004)	92004-Y002	2
STUD,8X190.5 (Ref # 92004A)	92004-Y004	2
RING-SNAP (Ref # 92033)	92033-Y012	1
PIN,8X14 (Ref # 92043)	92043-Y012	4
BEARING-BALL,6203 (Ref # 92045)	92045-Y006	1
BEARING-BALL,6204 (Ref # 92045A)	92045-Y007	1
BEARING-NEEDLE (Ref # 92046)	92046-Y003	1
SEAL-OIL,19.8X30X5 (Ref # 92049)	92049-Y001	1
SEAL-OIL,20X32X6 (Ref # 92049A)	92049-Y004	1
PLUG,DRAIN (Ref # 92066)	92066-Y003	1
PLUG (Ref # 92066A)	92066-Y005	1
PLUG (Ref # 92066B)	92066-Y007	1
BUSHING-RUBBER (Ref # 92092)	92092-Y002	1
BUSHING (Ref # 92139)	92139-Y001	2
BUSHING (Ref # 92139A)	92139-Y002	1
SPRING (Ref # 92145)	92145-Y001	1
SPRING,KICK DRIVEN GEAR (Ref # 92145A)	92145-Y011	1
COLLAR (Ref # 92152)	92152-Y006	1
BOLT,FLANGE,8X12 (Ref # 92153)	92153-Y001	2
BOLT,FLANGE,8X45 (Ref # 92153A)	92153-Y036	6

2009 KFX[®] 90

PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
BOLT,FLANGE,8X60 (Ref # 92153B)	92153-Y038	1
BOLT,FLANGE,6X28 (Ref # 92153C)	92153-Y052	1
BOLT,FLANGE,6X35 (Ref # 92153D)	92153-Y053	7
BOLT,FLANGE,6X45 (Ref # 92153E)	92153-Y054	1
BOLT,5X10 (Ref # 92153F)	92153-Y058	3
WASHER,8MM (Ref # 92200)	92200-Y001	1
WASHER,10MM (Ref # 92200A)	92200-Y002	1
WASHER (Ref # 92200B)	92200-Y008	1