

Ignition System

Let the Good Times Roll®

Exploded view diagram of a Kawasaki engine assembly. The diagram shows the following components and their part numbers:

- Ref. Fuel Injection:** 21121, 92152, 92015, (21150A), (21150B), (21150C), (21150), (21150A), (21150B), (21150C).
- Ref. Cylinder Head Cover:** 92037, 92070/A, 92070/A, 92070/A, 92070/A.
- Ref. Camshaft(s) / Tensioner:** (59026), 92072A, 92009, 59026, 92009.
- Ref. Engine Cover(s):** 130, 92200, 21007A, 610.
- Ref. Cylinder Head:** 92043, 13061, 92150, 21007.
- Ref. Crankshaft:** 21176, 92055, 92002, 92072, 92072.

The diagram also includes a "FRONT" arrow indicating the orientation of the engine.

2019 JET SKI® ULTRA® LX

PARTS LIST

Ignition System

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,8X25 (Ref # 130)	130CD0825	1
BOSS,CAM SENSOR (Ref # 13061)	13061-1687	1
ROTOR,EX CAM (Ref # 21007)	21007-3742	1
ROTOR,PULSING (Ref # 21007A)	21007-3744	1
COIL-IGNITION (Ref # 21121)	21121-0720	2
CORD-ASSY,#1,L=340 (Ref # 21150)	21150-0006	1
CORD-ASSY,#2,L=450 (Ref # 21150A)	21150-0007	1
CORD-ASSY,#3,L=540 (Ref # 21150B)	21150-0008	1
CORD-ASSY,#4,L=600 (Ref # 21150C)	21150-0009	1
SENSOR,CAM ANGLE (Ref # 21176)	21176-1077	1
COIL-PULSING (Ref # 59026)	59026-3702	1
ROLLER,4X8 (Ref # 610)	610A0408	1
BOLT,6X16 (Ref # 92002)	92002-3728	1
SCREW,5X12 (Ref # 92009)	92009-1296	4
NUT,6MM (Ref # 92015)	92015-3767	2
CLAMP,CORD (Ref # 92037)	92037-1603	3
PIN (Ref # 92043)	92043-1575	1
RING-O (Ref # 92055)	92055-1639	1
PLUG-SPARK,CR9EKB(NGK) (Ref # 92070)	92070-0050	4
PLUG-SPARK,CR8EKB(NGK) (Ref # 92070A)	92070-0708	4
BAND,L=188.85 (Ref # 92072)	92072-0105	2
BAND,L=152 (Ref # 92072A)	92072-3874	1
BOLT,6X18 (Ref # 92150)	92150-1645	1
BOLT,6X70 (Ref # 92150A)	92150-3753	2
COLLAR (Ref # 92152)	92152-3738	4
WASHER,8.0X22.0X1.5 (Ref # 92200)	92200-0174	1