

Transmission

Let the Good Times Roll®

Exploded view diagram of a mechanical assembly, likely a gearbox or transmission, showing various components and their assembly sequence. The diagram includes a "FRONT" arrow pointing towards the top left.

Key components and part numbers shown:

- Gears:** 13262A, 13262G, 13262I, 13262, 13262E, 13262F, 13262D, 13262B, 13262C, 13262H.
- Shafts:** 13127, 600, 13128.
- Bearings and Seals:** 92045, 92045A, 92045B, 92045C, 92045D, 92045E, 92045F, 92045G, 92045H, 92045I, 92045J, 92045K, 92045L, 92045M, 92045N, 92045O, 92045P, 92045Q, 92045R, 92045S, 92045T, 92045U, 92045V, 92045W, 92045X, 92045Y, 92045Z.
- Other Components:** 92200, 92200A, 92200B, 92200C, 92200D, 92200E, 92200F, 92200G, 92200H, 92200I, 92200J, 92200K, 92200L, 92200M, 92200N, 92200O, 92200P, 92200Q, 92200R, 92200S, 92200T, 92200U, 92200V, 92200W, 92200X, 92200Y, 92200Z, 92033, 92033A, 92033B, 92033C, 92033D, 92033E, 92033F, 92033G, 92033H, 92033I, 92033J, 92033K, 92033L, 92033M, 92033N, 92033O, 92033P, 92033Q, 92033R, 92033S, 92033T, 92033U, 92033V, 92033W, 92033X, 92033Y, 92033Z, 92139, 92139A, 92139B, 92139C, 92139D, 92139E, 92139F, 92139G, 92139H, 92139I, 92139J, 92139K, 92139L, 92139M, 92139N, 92139O, 92139P, 92139Q, 92139R, 92139S, 92139T, 92139U, 92139V, 92139W, 92139X, 92139Y, 92139Z, 92152, 92152A, 92152B, 92152C, 92152D, 92152E, 92152F, 92152G, 92152H, 92152I, 92152J, 92152K, 92152L, 92152M, 92152N, 92152O, 92152P, 92152Q, 92152R, 92152S, 92152T, 92152U, 92152V, 92152W, 92152X, 92152Y, 92152Z, 92210, 92210A, 92210B, 92210C, 92210D, 92210E, 92210F, 92210G, 92210H, 92210I, 92210J, 92210K, 92210L, 92210M, 92210N, 92210O, 92210P, 92210Q, 92210R, 92210S, 92210T, 92210U, 92210V, 92210W, 92210X, 92210Y, 92210Z.

2019 NINJA® ZX™-10R ABS

PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
SHAFT-TRANSMISSION INPUT,15T (Ref # 13127)	13127-0671	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-0670	1
SPROCKET-OUTPUT,17T,#525 (Ref # 13144)	13144-0004	1
GEAR,INPUT 5TH,20T (Ref # 13262)	13262-1203	1
GEAR,INPUT 6TH,23T (Ref # 13262A)	13262-1204	1
GEAR,OUTPUT 5TH,31T (Ref # 13262B)	13262-1205	1
GEAR,OUTPUT 6TH,32T (Ref # 13262C)	13262-1206	1
GEAR,OUTPUT LOW,39T (Ref # 13262D)	13262-1207	1
GEAR,OUTPUT 3RD,35T (Ref # 13262E)	13262-1357	1
GEAR,OUTPUT 4TH,31T (Ref # 13262F)	13262-1358	1
GEAR,INPUT 2ND,18T (Ref # 13262G)	13262-1359	1
GEAR,OUTPUT 2ND,40T (Ref # 13262H)	13262-1360	1
GEAR,INPUT 3RD&4TH,18T&18T (Ref # 13262I)	13262-1384	1
BALL-STEEL,5/32 (Ref # 600)	600A0500	3
RING-SNAP,25.9X30.6X1.2 (Ref # 92033)	92033-1037	5
RING-SNAP,T=1.5 (Ref # 92033A)	92033-1249	1
BEARING-BALL,830045-5SH2 (Ref # 92045)	92045-0047	1
BEARING-BALL,DG2152RDDSH2 (Ref # 92045A)	92045-0048	1
BEARING-BALL,63/22LU (Ref # 92045B)	92045-0156	1
BEARING-BALL,63/28 (Ref # 92045C)	92045-1189	1
RING-O,21.5X1.5 (Ref # 92055)	92055-1293	1
BUSHING,GEAR,6TH IN (Ref # 92139)	92139-0036	1
BUSHING,GEAR,LOW OUT (Ref # 92139A)	92139-0038	1
BUSHING,25.0X31.0X9.4 (Ref # 92139B)	92139-0309	2
BUSHING,28.1X31.0X13.5 (Ref # 92139C)	92139-0324	1
BUSHING,28.1X31.0X11.5 (Ref # 92139D)	92139-0734	1
COLLAR (Ref # 92152)	92152-0885	1
WASHER,28.3X34.0X1.6 (Ref # 92200)	92200-0050	5
WASHER,22.1X32.0X1.4 (Ref # 92200A)	92200-0138	2

2019 NINJA® ZX™-10R ABS

PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
WASHER,25.8X40.5X1.5 (Ref # 92200B)	92200-1522	2
WASHER,25.2X37.0X1.0 (Ref # 92200C)	92200-1523	2
WASHER (Ref # 92200D)	92200-1720	1
NUT,20MM (Ref # 92210)	92210-0850	1