


## 2020 MULE 4000 TRANS™ PARTS DIAGRAM

Air Cleaner



## 2020 MULE 4000 TRANS™ PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR (Ref # 11010)	11010-0885	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-1290	1
GASKET,AIR FILTER (Ref # 11061)	11061-1078	1
BOLT-FLANGED,6X18 (Ref # 130)	130BA0618	1
BOLT-FLANGED,8X14 (Ref # 130A)	130BB0814	1
BREATHER (Ref # 14069)	14069-0018	1
DUCT,RR BAR-A/C (Ref # 14073)	14073-0235	1
DUCT (Ref # 14073A)	14073-0773	1
DUCT (Ref # 14073B)	14073-0784	1
TRIM-SEAL (Ref # 39145)	39145-1133	1
WASHER,6.5X16X1.0 (Ref # 92022)	92022-1093	1
CLAMP,HOSE CLIP (Ref # 92037)	92037-1460	1
CLAMP,HARNESS,L=100 (Ref # 92037A)	92037-1636	1
CLAMP (Ref # 92037B)	92037-1678	1
PLUG (Ref # 92066)	92066-0914	1
COLLAR (Ref # 92152)	92152-2069	1
CLAMP (Ref # 92170)	92170-1491	1
CLAMP (Ref # 92170A)	92170-1674	1
CLAMP,18.8MM (Ref # 92171)	92171-2056	1
TUBE,CRANKCASE-BREATHER (Ref # 92192)	92192-1285	1
TUBE,BREATHER-INTAKE DUCT (Ref # 92192A)	92192-1855	1