


2020 MULE 4000 TRANS™ PARTS DIAGRAM

Air Cleaner-Belt Converter



2020 MULE 4000 TRANS™ PARTS LIST

Air Cleaner-Belt Converter

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR (Ref # 11010)	11010-0172	1
CASE-AIR FILTER,CAP (Ref # 11011)	11011-0135	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-0037	1
BOLT-FLANGED,8X40 (Ref # 130)	130BA0840	1
HOLDER (Ref # 13280)	13280-0312	1
DUCT,AIR FILTER-CVT (Ref # 14073)	14073-0198	1
DUCT,BAR-AIR FILTER (Ref # 14073A)	14073-0237	1
NUT,8MM (Ref # 92015)	92015-1432	1
WASHER,9X28X2.3 (Ref # 92022)	92022-1632	1
COLLAR (Ref # 92027)	92027-4012	1
RING-O,122X4 (Ref # 92055)	92055-0167	1
DAMPER (Ref # 92075)	92075-1736	1
CLAMP (Ref # 92170)	92170-1674	1
CLAMP (Ref # 92170A)	92170-1764	1
CLAMP (Ref # 92171)	92171-0225	1