


## 2020 MULE 4000 TRANS™ PARTS DIAGRAM

Fuel Pump

E1520



## 2020 MULE 4000 TRANS™ PARTS LIST

### Fuel Pump

ITEM NAME	PART NUMBER	QUANTITY
PLATE (Ref # 13272)	13272-1398	1
COVER (Ref # 14092)	14092-1044	1
RELAY-ASSY (Ref # 27002)	27002-1088	1
FILTER-FUEL (Ref # 49019)	49019-0013	1
PUMP-FUEL (Ref # 49040)	49040-0718	1
TUBE-ASSY,FUEL (Ref # 51044)	51044-0897	1
CHAMBER-FUEL (Ref # 51072)	51072-0003	1
O RING (Ref # 670)	670E5090	1
BOLT,FUEL PUMP (Ref # 92154)	92154-1326	1
CLAMP (Ref # 92171)	92171-0453	1
CLAMP (Ref # 92171A)	92171-0476	1