


2020 MULE 4000 TRANS™ PARTS DIAGRAM

Labels



2020 MULE 4000 TRANS™ PARTS LIST

Labels

ITEM NAME	PART NUMBER	QUANTITY
LABEL,OPERATING HOOD (Ref # 56030)	56030-0267	1
LABEL-MANUAL,BRAKE FLUID LEVEL (Ref # 56031)	56031-1818	1
LABEL-MANUAL,IGNITION (Ref # 56033)	56033-0212	1
LABEL-MANUAL,POWER STEERING (Ref # 56033A)	56033-0213	1
LABEL-MANUAL,DIFF MODE (Ref # 56033B)	56033-1183	1
LABEL-MANUAL,SHIFT (Ref # 56033C)	56033-1205	1
LABEL-BRAND (Ref # 56038)	56038-2782	1
LABEL-SPECIFICATION,TIRE (Ref # 56053)	56053-1631	1
LABEL-WARNING,HOT SURFACES (Ref # 56070)	56070-0051	1
LABEL-WARNING,BONNET OPERATION (Ref # 56070A)	56070-0053	1
LABEL-WARNING,SHIFT CAUTION (Ref # 56071)	56071-0128	1
LABEL-WARNING,TRAILER HITCH (Ref # 56071A)	56071-0332	1
LABEL-WARNING,CAB FRAME (Ref # 56071B)	56071-0492	1
LABEL-WARNING,CARGO BED,4P (Ref # 56071C)	56071-0637	1
LABEL-WARNING,CARGO BED (Ref # 56071D)	56071-0638	1
LABEL-WARNING,GENERAL (Ref # 56071E)	56071-0645	1
LABEL-WARNING,GASOLINE (Ref # 56071F)	56071-7501	1
LABEL-WARNING,REAR SEAT (Ref # 56071G)	56071-7513	1