

Generator

Let the Good Times Roll®

Exploded view diagram of the front engine assembly. The diagram shows the following components and their assembly sequence:

- Ref. Water Pump**: Reference to the water pump assembly.
- 21001**: Main engine block.
- 21007**: Component mounted on the engine block.
- 14093**: Component mounted on the engine block.
- 92045**: Component mounted on the engine block.
- 92172C**: Component mounted on the engine block.
- 13272**: Component mounted on the engine block.
- 92004**: Component mounted on the engine block.
- 31011**: Component mounted on the engine block.
- 92154D**: Component mounted on the engine block.
- 43094**: Component mounted on the engine block.
- 92026**: Component mounted on the engine block.
- 92154C**: Component mounted on the engine block.
- 59091**: Component mounted on the engine block.
- 92210**: Component mounted on the engine block.
- 92152**: Component mounted on the engine block.
- 92210B**: Component mounted on the engine block.
- 92139**: Component mounted on the engine block.
- 92210A**: Component mounted on the engine block.
- 92154A**: Component mounted on the engine block.
- 31011A**: Component mounted on the engine block.
- 13280**: Component mounted on the engine block.
- 21066**: Component mounted on the engine block.
- 92172A**: Component mounted on the engine block.
- 92172B**: Component mounted on the engine block.
- 13280A**: Component mounted on the engine block.
- 92172**: Component mounted on the engine block.
- 14093A**: Component mounted on the engine block.
- 92154**: Component mounted on the engine block.
- Ref. Crankcase**: Reference to the crankcase assembly.
- 92154B**: Component mounted on the crankcase.

The diagram includes a **FRONT** arrow indicating the orientation of the assembly.

2017 MULE PRO-DXT™ EPS LE DIESEL

Kawasaki
Let the Good Times Roll®

PARTS LIST

Generator

ITEM NAME	PART NUMBER	QUANTITY
PLATE,RETAINER (Ref # 13272)	13272-2135	1
HOLDER (Ref # 13280)	13280-0864	1
HOLDER,BRUSH (Ref # 13280A)	13280-0865	1
COVER (Ref # 14093)	14093-0450	1
COVER (Ref # 14093A)	14093-0451	1
GENERATOR (Ref # 21001)	21001-0613	1
ROTOR (Ref # 21007)	21007-0637	1
REGULATOR-VOLTAGE (Ref # 21066)	21066-0749	1
FRAME (Ref # 31011)	31011-0027	1
FRAME (Ref # 31011A)	31011-0028	1
ADJUSTER (Ref # 43094)	43094-0007	1
PULLEY (Ref # 59091)	59091-0015	1
STUD (Ref # 92004)	92004-0751	2
SPACER (Ref # 92026)	92026-0821	1
BEARING-BALL (Ref # 92045)	92045-0812	1
BEARING-BALL (Ref # 92045A)	92045-0816	1
BUSHING (Ref # 92139)	92139-0861	1
COLLAR (Ref # 92152)	92152-2198	1
BOLT (Ref # 92154)	92154-2074	3
BOLT (Ref # 92154A)	92154-2075	2
BOLT,FLANGED,10X45 (Ref # 92154B)	92154-2076	1
BOLT (Ref # 92154C)	92154-2077	1
BOLT,FLANGED,8X20 (Ref # 92154D)	92154-2078	1
SCREW (Ref # 92172)	92172-0989	6
SCREW (Ref # 92172A)	92172-0990	1
SCREW (Ref # 92172B)	92172-0991	2
SCREW (Ref # 92172C)	92172-1096	4
NUT (Ref # 92210)	92210-1474	1
NUT (Ref # 92210A)	92210-1475	2

2017 MULE PRO-DXT™ EPS LE DIESEL



PARTS LIST

Generator

ITEM NAME	PART NUMBER	QUANTITY
NUT (Ref # 92210B)	92210-1476	1