


2008 Vulcan® 1600 Nomad™ PARTS DIAGRAM

Throttle



2008 Vulcan® 1600 Nomad™ PARTS LIST

Throttle

ITEM NAME	PART NUMBER	QUANTITY
BRACKET (Ref # 11051)	11051-1333	1
BRACKET (Ref # 11051A)	11051-1345	1
BRACKET,HIGH TENSION CORD (Ref # 11052)	11052-1067	1
GASKET,THROTTLE BODY (Ref # 11060)	11060-1928	1
PLATE,STARTER CABLE (Ref # 13271)	13271-1314	1
HOLDER (Ref # 13280)	13280-1139	1
HOLDER (Ref # 13280A)	13280-1154	1
PLATE-POSITION,25KW (Ref # 14014)	14014-1142	1
SCREW-THROTTLE STOP (Ref # 16021)	16021-1227	1
INSULATOR (Ref # 16073)	16073-3707	1
VALVE (Ref # 16126)	16126-1372	1
THROTTLE-ASSY (Ref # 16163)	16163-1126	1
BODY-THROTTLE (Ref # 16182)	16182-0001	1
PIPE-COMP (Ref # 31064)	31064-1242	1
STAY (Ref # 35063)	35063-0030	1
STAY (Ref # 35063A)	35063-0038	1
NOZZLE-INJECTION (Ref # 49033)	49033-3707	1
PIPE-INJECTION (Ref # 49056)	49056-0002	1
MANIFOLD-INTAKE (Ref # 59076)	59076-0002	1
BOLT,FLANGED,6X14X13.5 (Ref # 92002)	92002-1595	1
SCREW,4X6 (Ref # 92009)	92009-1903	1
CLAMP,HOSE CLIP (Ref # 92037)	92037-1181	1
CLAMP,FUEL TUBE (Ref # 92037A)	92037-1271	1
PIN,THROTTLE BODY (Ref # 92043)	92043-1600	1
PIN,DELIVERY PIPE (Ref # 92043A)	92043-1601	1
RING-O,7.8X3.5 (Ref # 92055)	92055-029	1
RING-O,INJECTION NOZZLE (Ref # 92055A)	92055-1622	1
SEAL (Ref # 92093)	92093-0072	1
BOLT,5X10,25KW (Ref # 92151)	92151-1528	1

2008 Vulcan® 1600 Nomad™ PARTS LIST

Throttle

ITEM NAME	PART NUMBER	QUANTITY
BOLT, THROTTLE BODY (Ref # 92151A)	92151-1587	1
BOLT, 5X20 (Ref # 92153)	92153-0378	1
BOLT (Ref # 92153A)	92153-0379	1
DAMPER (Ref # 92161)	92161-1058	1
DAMPER (Ref # 92161A)	92161-1062	1
TUBE, REAR VALVE, RED (Ref # 92191)	92191-1367	1
TUBE, FRONT VALVE, BLUE (Ref # 92191A)	92191-1368	1
BOLT-SOCKET, 5X10 (Ref # 120)	120S0510	1
BOLT-SOCKET, 6X20 (Ref # 120A)	120Z0620	1
BOLT-FLANGED-SMALL, 6X25 (Ref # 132)	132J0625	1
TUBE (Ref # 92191B)	92191-1608	1
TUBE, THROTTLE-BOOST SENSOR (Ref # 92191C)	92191-1821	1
PLUG, 12X25 (Ref # 92068)	92068-006	1