


2007 Vulcan 1600 Nomad

PARTS DIAGRAM

Ignition System

Kawasaki

Let the Good Times Roll®



2007 Vulcan 1600 Nomad

PARTS LIST

Ignition System

ITEM NAME	PART NUMBER	QUANTITY
SCREW-PAN-WS-CROS,5X16 (Ref # 223)	223B0516	4
PLATE (Ref # 13270)	13270-1979	1
COIL-IGNITION,FR (Ref # 21121)	21121-0003	1
COIL-IGNITION,RR (Ref # 21121A)	21121-0004	1
GROMMET,HIGH TENSION (Ref # 21131)	21131-005	2
GROMMET,HIGH TENSION (Ref # 21132)	21132-005	2
CAP-ASSY-PLUG (Ref # 21160)	21160-0004	2
CAP-ASSY-PLUG (Ref # 21160A)	21160-1091	2
COIL-PULSING (Ref # 59026)	59026-1157	1
CLAMP,SPEED,L=43 (Ref # 92037)	92037-1290	2
PLUG-SPARK,X22EPR-U9(ND) (Ref # 92070)		AR
PLUG-SPARK,DPR7EA9(NGK) (Ref # 92070A)	92070-1125	AR
PLUG-SPARK,DPR6EA9(NGK) (Ref # 92070B)	92070-1138	4
PLUG-SPARK,X20EPR-U9(ND) (Ref # 92070C)		4
PLUG-SPARK,DPR5EA9(NGK) (Ref # 92070D)	92070-1250	AR
PLUG-SPARK,X16EPR-U9(ND) (Ref # 92070E)		AR
GROMMET,PLUG CAP (Ref # 92071)	92071-1184	4
BOLT,6X10 (Ref # 92151)	92151-3704	1
CLAMP (Ref # 92171)	92171-0129	3
CLAMP (Ref # 92171A)	92171-0130	1
NUT,CAP,6MM (Ref # 92210)	92210-0003	4