


## 2008 Vulcan® 1600 Nomad™ PARTS DIAGRAM

Front Fork(D7F/D7FA/D8F/D8FA)



## 2008 Vulcan® 1600 Nomad™ PARTS LIST

Front Fork(D7F/D7FA/D8F/D8FA)

ITEM NAME	PART NUMBER	QUANTITY
GASKET,6.2X12X0.3 (Ref # 11060)	11060-1994	1
PIPE-LEFT FORK OUTER (Ref # 44005)	44005-1436	1
PIPE-RIGHT FORK OUTER (Ref # 44006)	44006-0006	1
PIPE-FORK INNER (Ref # 44013)	44013-0024	1
CYLINDER-SET-FORK (Ref # 44023)	44023-0004	1
SPRING-FRONT FORK (Ref # 44026)	44026-0050	1
SEAT-FORK SPRING (Ref # 44029)	44029-1154	1
COVER-FORK,CNT (Ref # 44033)	44033-0013	1
COVER-FORK,INNER,LH (Ref # 44033A)	44033-0027	1
COVER-FORK,INNER,RH (Ref # 44033B)	44033-0028	1
COVER-FORK,RR,LH (Ref # 44033C)	44033-0029	1
COVER-FORK,RR,RH (Ref # 44033D)	44033-0031	1
HOLDER-FORK UNDER (Ref # 44037)	44037-0021	1
HOLDER-FORK UPPER (Ref # 44039)	44039-0019	1
BOLT,SOCKET,FORK CYLINDER (Ref # 44041)	44041-040	1
GASKET (Ref # 44045)	44045-057	1
BUSHING-FRONT FORK (Ref # 44065)	44065-0003	1
BUSHING-FRONT FORK (Ref # 44065A)	44065-1143	1
DAMPER-ASSY,FORK,LH (Ref # 44071)	44071-0156	1
DAMPER-ASSY,FORK,RH (Ref # 44071A)	44071-0157	1
WASHER (Ref # 92022)	92022-1299	1
SPACER,FORK,L=141.5 (Ref # 92026)	92026-0062	1
RING-SNAP (Ref # 92033)	92033-1077	1
SEAL-OIL (Ref # 92049)	92049-0007	1
RING-O (Ref # 92055)	92055-1123	1
PLUG (Ref # 92066)	92066-0032	1
SEAL,FORK OUTER TUBE (Ref # 92093)	92093-1480	1
BOLT,SOCKET,10X25 (Ref # 92151)	92151-1358	1
BOLT (Ref # 92153)	92153-0300	1

## 2008 Vulcan® 1600 Nomad™ PARTS LIST

Front Fork(D7F/D7FA/D8F/D8FA)

ITEM NAME	PART NUMBER	QUANTITY
BOLT,SOCKET,6X10 (Ref # 92153A)	92153-0411	1
BOLT (Ref # 92153B)	92153-0425	1
DAMPER (Ref # 92161)	92161-1343	1
WASHER (Ref # 92200)	92200-1253	1