


2020 NINJA H2™ R

PARTS DIAGRAM

Air Chamber



2020 NINJA H2™ R

PARTS LIST

Air Chamber

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,SOLENOID VALVE (Ref # 11056)	11056-4452	1
GASKET,CHAMBER (Ref # 11061)	11061-0949	1
GASKET,BLOWOFF VALVE (Ref # 11061A)	11061-0950	1
CHAMBER,INTAKE (Ref # 12026)	12026-0012	1
CONNECTOR (Ref # 13159)	13159-0016	2
HOLDER,CHAMBER (Ref # 13280)	13280-0801	1
INSULATOR (Ref # 16073)	16073-0129	4
VALVE,SOLENOID (Ref # 16126)	16126-0751	1
VALVE-ASSY-RELIEF,BLOWOFF (Ref # 16130)	16130-0004	1
NOZZLE-INJECTION (Ref # 49033)	49033-0035	4
FITTING (Ref # 92005)	92005-0125	1
FITTING (Ref # 92005A)	92005-0826	1
WASHER,5.5X10.5X0.8 (Ref # 92022)	92022-037	12
CLAMP,TUBE (Ref # 92037)	92037-147	1
CLAMP,RESERVE TANK (Ref # 92037A)	92037-1586	2
CLAMP,7.8MM (Ref # 92037B)	92037-2116	5
RING-O,INJECTION NOZZLE (Ref # 92055)	92055-0124	4
RING-O,65.8X3 (Ref # 92055A)	92055-0815	4
BOLT,SOCKET,5X18 (Ref # 92154)	92154-1450	15
BOLT,FLANGED,5X14 (Ref # 92154A)	92154-1680	7
BOLT,FLANGED,5X95 (Ref # 92154B)	92154-1681	5
BOLT,SHOULDER,5X18 (Ref # 92154C)	92154-1764	4
CLAMP (Ref # 92170)	92170-1036	1
CLAMP (Ref # 92171)	92171-0058	1
TUBE,DIFFUSER (Ref # 92192)	92192-1415	1
TUBE,BLOWOFF VALVE-AIR FILTER (Ref # 92192A)	92192-1416	1
TUBE,SOLENOID-BLOWOFF VALVE (Ref # 92192B)	92192-1417	1
TUBE,SOLENOID-THROTTLE BODY (Ref # 92192C)	92192-1418	1
TUBE,SOLENOID-CHAMBER (Ref # 92192D)	92192-1419	1

2020 NINJA H2™ R

PARTS LIST

Air Chamber

ITEM NAME	PART NUMBER	QUANTITY
NUT,CAP,6MM (Ref # 92210)	92210-0170	1
BOLT-FLANGED-SMALL,8X30 (Ref # 132)	132BC0830	2
PIN-DOWEL,6X12 (Ref # 551)	551A0612	2
O RING,8MM (Ref # 670)	670E1508	2