


# 2019 MULE SX™ 4x4

## PARTS DIAGRAM

### Ignition Switch



# 2019 MULE SX™ 4x4

## PARTS LIST

### Ignition Switch

| ITEM NAME                                | PART NUMBER | QUANTITY |
|------------------------------------------|-------------|----------|
| SWITCH-COMP,OUTLET,12V (Ref # 13151)     | 13151-0556  | 1        |
| LAMP-ASSY,PARKING&OIL TEMP (Ref # 23016) | 23016-0590  | 1        |
| SWITCH-ASSY-IGNITION (Ref # 27005)       | 27005-1146  | 1        |
| KEY-LOCK,BLANK (Ref # 27008)             | 27008-1153  | 1        |
| KEY-LOCK,BLANK (Ref # 27008A)            | 27008-1157  | 1        |
| SWITCH,BRAKE (Ref # 27010)               | 27010-0724  | 1        |
| SWITCH,OUTER (Ref # 27010A)              | 27010-0806  | 1        |
| PLUG (Ref # 92066)                       | 92066-0922  | 1        |
| BULB,12V 1.7W,T10 (Ref # 92069)          | 92069-1059  | 2        |
| SPRING,REAR BRAKE SWITCH (Ref # 92145)   | 92145-7508  | 1        |
| NUT,IGNITION SWITCH (Ref # 92210)        | 92210-1264  | 1        |