



# 1988 LTD

## PARTS DIAGRAM

### Valve(s)

E1210-0008



# 1988 LTD

## PARTS LIST

### Valve(s)

ITEM NAME	PART NUMBER	QUANTITY
GASKET,16X19.7X1.5 (Ref # 11009)	11009-1106	2
VALVE-INTAKE (Ref # 12004)	12004-1003	2
VALVE-EXHAUST (Ref # 12005)	12005-1003	2
RETAINER-VALVE SPRING (Ref # 12009)	12009-1001	4
COLLET,SPLIT KEEPER (Ref # 12011)	12011-1002	8
ARM-ROCKER (Ref # 12016)	12016-1002	4
SHAFT-ROCKER,RH (Ref # 12020)	12020-1003	2
SHAFT-ROCKER,LH (Ref # 12020A)	12020-1006	2
SEAT-SPRING,THROTTLE VALVE (Ref # 16007)	16007-1012	4
SPRING-ENGINE VALVE,INNER (Ref # 49078)	12007-1001	4
SPRING-ENGINE VALVE,OUTER (Ref # 49078A)	12007-1002	4
SCREW,6MM (Ref # 92009)	92009-1032	4
NUT,6MM (Ref # 92015)	92016-061	4
SEAL-OIL,RVC2-5.5X8.5X8.3 (Ref # 92049)	92049-1062	4
O RING,10MM (Ref # 670)	670D1510	2