


2010 Z1000 PARTS DIAGRAM

Ignition Switch/Locks/Reflectors



2010 Z1000 PARTS LIST

Ignition Switch/Locks/Reflectors

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,REFLECTOR (Ref # 11047)	11047-1470	1
BRACKET,SIDE STAND SWITCH (Ref # 11054)	11054-1904	1
BRACKET,IGNITION SWITCH (Ref # 11056)	11056-0161	1
BRACKET,SEAT,LOCK (Ref # 11056A)	11056-0181	1
ROTOR,LOCK,TANK CAP (Ref # 21007)	21007-5068	1
SWITCH-ASSY-IGNITION (Ref # 27005)	27005-0059	1
KEY-LOCK,BLANK (Ref # 27008)	27008-0069	1
SWITCH,SIDE STAND (Ref # 27010)	27010-0112	1
SWITCH,REAR BRAKE (Ref # 27010A)	27010-1486	1
LOCK-ASSY,SEAT STRIKER (Ref # 27016)	27016-0035	1
LOCK-ASSY,SEAT (Ref # 27016A)	27016-5365	1
SWITCH-ASSY (Ref # 27045)	27045-5413	1
REFLECTOR-REFLEX,FR,SIDE (Ref # 28012)	28012-0001	2
REFLECTOR-REFLEX (Ref # 28012A)	28012-0002	2
REFLECTOR-REFLEX (Ref # 28012B)	28012-1077	1
TRIM,L=60 (Ref # 53044)	53044-1249	1
TRIM,L=48 (Ref # 53044A)	53044-1324	1
GUARD,SEAT STRIKER (Ref # 55020)	55020-0483	1
BOLT,6X12 (Ref # 92002)	92002-1132	2
NUT,FLANGED,6MM (Ref # 92015)	92015-1367	2
COLLAR,L=9.6 (Ref # 92027)	92027-1045	2
BAND,L=148 (Ref # 92072)	92072-3768	1
DAMPER (Ref # 92075)	92075-1564	4
SPRING,BRAKE LAMP SWITCH (Ref # 92145)	92145-0761	1
BOLT,TORX,6X22 (Ref # 92151)	92151-1946	2
COLLAR (Ref # 92152)	92152-1074	1
BOLT,SOCKET,6X12 (Ref # 92153)	92153-1617	2
BOLT,SOCKET,6X22 (Ref # 92154)	92154-0031	1
DAMPER (Ref # 92161)	92161-0117	2

2010 Z1000 PARTS LIST

Ignition Switch/Locks/Reflectors

ITEM NAME	PART NUMBER	QUANTITY
DAMPER (Ref # 92161A)	92161-0118	1
SCREW,TAPPING,5X10 (Ref # 92172)	92172-1061	1
WASHER,6X20X1.6 (Ref # 92200)	92200-0212	2
NUT,CAP,6MM (Ref # 92210)	92210-0003	1
NUT,FLANGED,5MM (Ref # 92210A)	92210-0007	3
BOLT-FLANGED,6X12 (Ref # 130)	130BA0612	1
BOLT-FLANGED-SMALL,6X25 (Ref # 132)	132BA0625	2
SCREW-CSK-CROSS,6X30 (Ref # 221)	221AB0630	2
NUT-HEX (Ref # 311)	311AB0500	2