


1995 Vulcan 88

PARTS DIAGRAM

Battery Case



1995 Vulcan 88

PARTS LIST

Battery Case

| ITEM NAME | PART NUMBER | QUANTITY |
|---|-------------|----------|
| BOLT-FLANGED,6X14 (Ref # 130) | 130C0614 | 2 |
| BOLT-FLANGED (Ref # 130A) | 130D0610 | 2 |
| BOLT-FLANGED-SMALL,6X14 (Ref # 132) | 132E0614 | 8 |
| BOLT-FLANGED-SMALL (Ref # 132A) | 132E0820 | 4 |
| BOLT-FLANGED-SMALL (Ref # 132B) | 132G0612 | 3 |
| BOLT-FLANGED-SMALL,6X10 (Ref # 132C) | 132H0610 | 4 |
| SCREW-PAN-WS-CROS (Ref # 223) | 223B0510 | 2 |
| SCREW-PAN-WSP-CROS (Ref # 236) | 236D0612 | 2 |
| CAP,SWING ARM (Ref # 11012) | 11012-1575 | 2 |
| BRACKET,ELECTRIC BASE (Ref # 11045) | 11045-1451 | 1 |
| BRACKET,IGNITER (Ref # 11045A) | 11045-1452 | 1 |
| BRACKET,JUNCTION BOX (Ref # 11045B) | 11045-1453 | 1 |
| BRACKET,FUEL PUMP (Ref # 11045C) | 11045-1454 | 1 |
| BRACKET,FUEL FILTER (Ref # 11045D) | 11045-1455 | 1 |
| BRACKET,IGNITION COIL (Ref # 11045E) | 11045-1622 | 1 |
| COVER,HEAD GUSSET,LH (Ref # 14024) | 14024-1457 | 1 |
| COVER,SEAT (Ref # 14024A) | 14024-1459 | 1 |
| COVER,HEAD GUSSET,RH (Ref # 14024B) | 14024-1682 | 1 |
| CASE-BATTERY (Ref # 32097) | 32097-1130 | 1 |
| GRIP-FRAME,LWR,LH (Ref # 32109) | 32109-1157 | 1 |
| GRIP-FRAME,LWR,RH (Ref # 32109A) | 32109-1158 | 1 |
| GRIP-FRAME,UPP (Ref # 32109B) | 32109-1159 | 1 |
| STAY,FRAME GRIP,LH (Ref # 35011) | 35011-1336 | 1 |
| STAY,FRAME GRIP,RH (Ref # 35011A) | 35011-1337 | 1 |
| SLEEVE,17.1X25X40 (Ref # 42036) | 42036-1213 | 2 |
| BOLT,6X12 (Ref # 92002) | 92002-1721 | 2 |
| SCREW,5X10 (Ref # 92009) | 92009-1651 | 3 |
| BEARING-NEEDLE,BHTM2530-1 (Ref # 92046) | 92046-1035 | 2 |
| SEAL-OIL,MHA25X33X5.7F (Ref # 92049) | 92049-1166 | 2 |

1995 Vulcan 88

PARTS LIST

Battery Case

| ITEM NAME | PART NUMBER | QUANTITY |
|-------------------------------------|-------------|----------|
| BAND,BATTERY (Ref # 92072A) | 92072-1313 | 1 |
| DAMPER,RUBBER (Ref # 92075) | 92075-078 | 3 |
| COLLAR,17.6X22.2X96.5 (Ref # 92143) | 92143-1083 | 1 |