


1987 Vulcan 88 SE PARTS DIAGRAM

Tires

F2210



1987 Vulcan 88 SE PARTS LIST

Tires

ITEM NAME	PART NUMBER	QUANTITY
TIRE,FR,100/90-19 57H,F11J(D) (Ref # 41002)	41002-1648	1
TIRE,RR,150/90-15 74H,K425AJ(D) (Ref # 41002A)	41002-1649	1
TUBE-TIRE,100/90-19(D) (Ref # 41022)	41022-1129	1
TUBE-TIRE,RR,150/90-15(D) (Ref # 41022A)	41022-1133	1
BAND-RIM,90.100/90-19(D) (Ref # 41023)	41023-1074	1
BAND-RIM,RR,130-150/90-15(D) (Ref # 41023A)	41023-1075	1
STOPPER-RIM,3.00(DUNLOP) (Ref # 41024)	41024-1004	1
RIM,FR,2.15X19 (Ref # 41025)	41025-1178	1
RIM,RR,3.00X15 (Ref # 41025A)	41025-1179	1
SPOKE-INNER,FR,195MMX128D (Ref # 41029)	41029-1174	1
SPOKE-INNER,RR,74MMX110D (Ref # 41029A)	41029-1175	1
SPOKE-OUTER,RR,72MMX68D (Ref # 41030)	41030-1115	1
NIPPLE-SPOKE (Ref # 41032)	41032-1062	1
NIPPLE-SPOKE (Ref # 41032A)	41032-1063	1
BALANCER-WHEEL,10G (Ref # 41075)	41075-1007	1
BALANCER-WHEEL,20G (Ref # 41075A)	41075-1008	1
BALANCER-WHEEL,30G (Ref # 41075B)	41075-1009	1
BALANCER-WHEEL (Ref # 41075C)	41075-1054	1
NUT-HEX-SMALL,8MM (Ref # 317)	317H0800	1
WASHER-PLAIN (Ref # 411)	411E0800	1