


2008 Vulcan® 1600 Mean Streak® PARTS DIAGRAM

Air Cleaner

E1130



2008 Vulcan® 1600 Mean Streak® PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
ELEMENT-AIR FILTER (Ref # 11013)	11013-1248	1
CASE-ASSY-AIR FILTER,RH (Ref # 11038)	11038-0005	1
BRACKET (Ref # 11053)	11053-0231	1
GASKET,AIR FILTER CASE (Ref # 11060)	11060-1968	1
DUCT,AIR FILTER (Ref # 14073)	14073-1739	1
VALVE,AIR SWITCHING (Ref # 16126)	16126-1437	1
DUCT-ASSY,CENTER (Ref # 39045)	39045-0003	1
ELBOW (Ref # 52014)	52014-1083	1
BOLT,FLANGED,6X14X13.5 (Ref # 92002)	92002-1595	1
SCREW,TAPPING,5X16 (Ref # 92009)	92009-1264	1
SCREW,PAN-WP-CROS,5X20 (Ref # 92009A)	92009-1905	1
CLAMP (Ref # 92037)	92037-1468	1
CLAMP,TUBE (Ref # 92037A)	92037-147	1
CLAMP (Ref # 92037B)	92037-1593	1
PLUG,DRAIN (Ref # 92066)	92066-1211	1
GROMMET,AIR FILTER (Ref # 92071)	92071-1028	1
SEAL,AIR FILTER CASE (Ref # 92093)	92093-1408	1
SEAL,DUCT,LH (Ref # 92093A)	92093-1459	1
SEAL (Ref # 92093B)	92093-1485	1
SEAL,DUCT,RH (Ref # 92093C)	92093-1491	1
BOLT,8X14 (Ref # 92151)	92151-1438	1
DAMPER (Ref # 92160)	92160-1594	1
DAMPER (Ref # 92161)	92161-0309	1
CLAMP,TUBE (Ref # 92170)	92170-1445	1
CLAMP (Ref # 92170A)	92170-1695	1
CLAMP (Ref # 92171)	92171-0790	1
TUBE,BREATHER (Ref # 92191)	92191-1406	1
TUBE,FR HEAD-AIR SWITCH (Ref # 92192)	92192-0001	1
TUBE,RR HEAD-AIR SWITCH (Ref # 92192A)	92192-0002	1

2008 Vulcan® 1600 Mean Streak® PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
TUBE,AIR SWITCH-AIR CLEANER (Ref # 92192B)	92192-0003	1
BOLT-SOCKET,6X16 (Ref # 120)	120S0616	1
BOLT-FLANGED-SMALL,6X16 (Ref # 132)	132J0616	1
TUBE-RUBBER,7X10X230 (Ref # 702)	702A07230	1
WASHER,8.5X20X1.6 (Ref # 92200)	92200-1463	1
CASE-AIR FILTER,LH (Ref # 11011)	11011-0020	1
CASE-AIR FILTER,COVER (Ref # 11011A)	11011-0021	1
CASE-AIR FILTER (Ref # 11011B)	11011-0083	1
CASE-AIR FILTER,LH (Ref # 11011C)	11011-1601	1
GROMMET,AIR FILTER (Ref # 92071A)	92071-1114	1