

Ignition System

Let the Good Times Roll®

Exploded view diagram of the front engine compartment showing the installation of the battery and associated wiring. The diagram includes labels for various components and their assembly points:

- FRONT**: Arrow indicating the front of the vehicle.
- 21150**: Battery.
- 92173**: Battery terminal post.
- 92070/A**: Spark plug.
- 21121**: Battery terminal bracket.
- 130**: Bolt.
- 11056**: Battery terminal bracket.
- 220**: Bolt.
- Ref. Frame**: Reference frame.
- Ref. Chassis Electrical Equipment**: Reference chassis electrical equipment.
- 26011**: Battery terminal bracket.
- 92072**: Battery terminal post.
- 92154**: Bolt.

2021 MULE PRO-FX™

PARTS LIST

Ignition System

ITEM NAME	PART NUMBER	QUANTITY
BRACKET (Ref # 11056)	11056-7248	1
COIL-IGNITION (Ref # 21121)	21121-0724	3
CORD-ASSY,HIGH TENSION (Ref # 21150)	21150-0013	1
WIRE-LEAD (Ref # 26011)	26011-0846	1
PLUG-SPARK,7026(TORCH) (Ref # 92070)	92070-0048	3
PLUG-SPARK,IFR6B11(NGK) (Ref # 92070A)		3
BAND,L=292.1 (Ref # 92072)	92072-3509	1
BOLT,FLANGED,10X14 (Ref # 92154)	92154-1383	1
CLAMP (Ref # 92173)	92173-1056	1
BOLT-FLANGED,8X20 (Ref # 130)	130BA0820	1
SCREW-PAN-CROS,5X25 (Ref # 220)	220AA0525	6