


# 2008 STX-15F PARTS DIAGRAM

Seat

F3146



## 2008 STX-15F PARTS LIST

### Seat

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,SEAT (Ref # 11049)	11049-3735	1
BRACKET (Ref # 11053)	11053-3785	1
PLATE,FRONT SEAT HOOK,OUTER (Ref # 13270)	13270-3910	1
HOOK,FRONT SEAT LOCK (Ref # 27012)	27012-3858	1
LOCK-ASSY,SEAT,F.BLACK (Ref # 27016)	27016-3744-6Z	1
LOCK-ASSY,FRONT SEAT (Ref # 27016A)	27016-3747	1
SEAT-ASSY,FR,RED (Ref # 53066A)	53066-3709-MG	1
SEAT-ASSY,FR,T.BLUE (Ref # 53066C)	53066-3709-340	1
SEAT-ASSY,RR,M.P.SILVER (Ref # 53066F)	53066-3710-13F	1
NUT,FLANGED,8MM (Ref # 92015)	92015-3709	3
NUT,6MM (Ref # 92015A)	92015-3767	2
BOLT,6X18 (Ref # 92150)	92150-3729	2
WASHER,6.5X20X1.5 (Ref # 92200)	92200-3715	2
WASHER,8.5X25X1.5 (Ref # 92200A)	92200-3717	3
WASHER,8.5X18X3 (Ref # 92200B)	92200-3761	2