


2004 STX-12F

PARTS DIAGRAM

Intake Silencer(JT1200-B1)

E1130



2004 STX-12F

PARTS LIST

Intake Silencer(JT1200-B1)

ITEM NAME	PART NUMBER	QUANTITY
CASE-AIR FILTER,FR (Ref # 11011)	11011-3703	1
CASE-AIR FILTER,RR (Ref # 11011A)	11011-3704	1
BRACKET (Ref # 11053)	11053-3725	1
PLATE (Ref # 13271)	13271-3880	1
DUCT,AIR FILTER-ASV (Ref # 14073)	14073-3794	1
DUCT,AIR FILTER-THOROTTLE (Ref # 14073A)	14073-3795	1
VALVE,AIR SWITCH (Ref # 16126)	16126-1433	1
BAFFLE (Ref # 18020)	18020-3703	1
BOOT,DRAIN (Ref # 49006)	49006-3718	2
TANK-OIL, SEPARATOR (Ref # 52001)	52001-3736	1
ARRESTER-FLAME (Ref # 59006)	59006-0019	1
ARRESTER-FLAME (Ref # 59006A)	59006-3719	1
BOLT,6X12 (Ref # 92002)	92002-3763	4
SCREW,M6X20 (Ref # 92009)	92009-3870	2
NUT,6MM (Ref # 92015)	92015-3767	2
WASHER,8.2X18X1.5 (Ref # 92022)	92022-3743	2
BAND,L=203.2 (Ref # 92072)	92072-3867	1
BAND (Ref # 92072A)	92072-3869	1
SEAL (Ref # 92093)	92093-3766	1
CLAMP (Ref # 92170)	92170-3764	3
CLAMP,TUBE (Ref # 92171)	92171-3710	6
CLAMP,BOOT (Ref # 92171A)	92171-3711	2
TUBE,4X9X450 (Ref # 92190)	92190-1062	1
TUBE (Ref # 92191)	92191-3959	2
TUBE,ASV-AIR CASE (Ref # 92191A)	92191-3960	1
TUBE,SEPARATOR-AIR CLEANER (Ref # 92191B)	92191-3998	1
TUBE,SEPARATOR-OILPLAN (Ref # 92192)	92192-3701	1
TUBE,HEAD-SEPARATOR (Ref # 92192A)	92192-3719	1
BOLT-FLANGED-SMALL (Ref # 132)	132Y0660	1

2004 STX-12F

PARTS LIST

Intake Silencer(JT1200-B1)



ITEM NAME	PART NUMBER	QUANTITY
BOLT-WSP-SMALL,8X20 (Ref # 155)	155R0820	2
BOLT-WP,6X16 (Ref # 156)	156R0616	8