


## 2007 Ultra LX PARTS DIAGRAM

Fuel Pump

E1520



## 2007 Ultra LX PARTS LIST

### Fuel Pump

| ITEM NAME                    | PART NUMBER | QUANTITY |
|------------------------------|-------------|----------|
| HOLDER (Ref # 13280)         | 13280-3735  | 1        |
| PUMP-FUEL (Ref # 49040)      | 49040-3719  | 1        |
| TUBE-ASSY,FUEL (Ref # 51044) | 51044-3705  | 1        |
| CLAMP (Ref # 92170)          | 92170-3760  | 1        |
| CLAMP (Ref # 92171)          | 92171-3716  | 1        |