


2008 Ultra LX PARTS DIAGRAM

Fuel Tank

F3173



2008 Ultra LX PARTS LIST

Fuel Tank

ITEM NAME	PART NUMBER	QUANTITY
GASKET,FUEL-FILLER (Ref # 11060)	11060-3780	1
BOOT (Ref # 49006)	49006-3719	1
VALVE-RELIEF (Ref # 49057)	49057-3707	1
TANK-FUEL (Ref # 51004)	51004-3742	1
CAP-TANK,FUEL (Ref # 51049)	51049-3726	1
JOINT (Ref # 59071)	59071-3736	1
FILLER,FUEL TANK (Ref # 59231)	59231-3727	1
CLAMP (Ref # 92037)	92037-3738	2
RIVET (Ref # 92039)	92039-3788	4
CHAIN,COVER,L=100 (Ref # 92057)	92057-3704	1
GROMMET (Ref # 92071)	92071-3841	1
BAND (Ref # 92072)	92072-3845	2
BAND (Ref # 92072A)	92072-3847	2
BAND,L=99 (Ref # 92072B)	92072-3871	9
TUBE,5.8X10.8X1000 (Ref # 92191)	92191-3736	1
TUBE,5.8X10.8X100 (Ref # 92191A)	92191-3828	1
TUBE,CORRUGATED,L=120 (Ref # 92192)	92192-3749	1
TUBE,CORRUGATED,L=700 (Ref # 92192A)	92192-3750	1
TUBE,FUEL TANK-FILLER (Ref # 92192B)	92192-3752	1
TUBE,CORRUGATED,L=350 (Ref # 92192C)	92192-3788	1
TUBE,86X89X300 (Ref # 92192D)	92192-3822	1
NUT,FILLER (Ref # 92210)	92210-3751	1