


2005 Vulcan 2000

PARTS DIAGRAM

Front Wheel



2005 Vulcan 2000

PARTS LIST

Front Wheel

| ITEM NAME | PART NUMBER | QUANTITY |
|--|-------------|----------|
| BEARING-BALL,#6005UU (Ref # 601) | 601B6005UU | 2 |
| AXLE,FR (Ref # 41068) | 41068-0028 | 1 |
| WHEEL-ASSY,FR (Ref # 41073) | 41073-0004 | 1 |
| RING-SNAP,47MM (Ref # 92033) | 92033-1042 | 1 |
| SEAL-OIL,BJN 32 47 5 (Ref # 92049) | 92049-1377 | 2 |
| COLLAR,FR AXLE,LH,L=44.5 (Ref # 92143) | 92143-1478 | 1 |
| COLLAR,FR AXLE,L=44 (Ref # 92152) | 92152-0182 | 2 |
| COLLAR,FR HUB,L=109 (Ref # 92152A) | 92152-1308 | 1 |