



2007 Vulcan 2000 PARTS DIAGRAM

Valve(s)

E1210



2007 Vulcan 2000 PARTS LIST

Valve(s)

| ITEM NAME | PART NUMBER | QUANTITY |
|----------------------------------------|-------------|----------|
| VALVE-INTAKE (Ref # 12004) | 12004-0001 | 4 |
| VALVE-EXHAUST (Ref # 12005) | 12005-0001 | 4 |
| RETAINER-VALVE SPRING (Ref # 12009) | 12009-0002 | 8 |
| COLLET (Ref # 12011) | 12011-0001 | 16 |
| ARM-ROCKER (Ref # 12016) | 12016-0015 | 2 |
| ARM-ROCKER (Ref # 12016A) | 12016-0016 | 2 |
| SHAFT-ROCKER,EXHAUST (Ref # 12020) | 12020-0001 | 2 |
| SHAFT-ROCKER,INTAKE (Ref # 12020A) | 12020-0002 | 2 |
| ADJUSTER-LASH (Ref # 12025) | 12025-1053 | 8 |
| SEAT-SPRING (Ref # 16007) | 16007-0001 | 8 |
| SPRING-ENGINE VALVE (Ref # 49078) | 49078-0001 | 8 |
| SEAL-OIL,RVC2 6 10.5 9.4 (Ref # 92049) | 92049-0009 | 8 |
| BOLT,6X38 (Ref # 92150) | 92150-1301 | 12 |