


2008 Vulcan® 2000 Classic LT PARTS DIAGRAM

Gear Change Mechanism

E1370



2008 Vulcan® 2000 Classic LT PARTS LIST

Gear Change Mechanism

ITEM NAME	PART NUMBER	QUANTITY
BOLT-STUD,6X18 (Ref # 172)	172BA0618	1
NUT-HEX (Ref # 311)	311BA0600	1
NUT-HEX,6MM (Ref # 311A)	311BB0600	1
CIRCLIP-TYPE-C,12MM (Ref # 480)	480J1200	1
CIRCLIP-TYPE-E,12MM (Ref # 482)	482J0200	1
DAMPER,PEDAL (Ref # 13063)	13063-002	2
LEVER-CHANGE (Ref # 13156)	13156-0007	1
PAWL (Ref # 13165)	13165-0001	1
LEVER,RH (Ref # 13168)	13168-0009	1
LEVER,LH (Ref # 13168A)	13168-0010	1
LEVER-COMP,POSITION (Ref # 13236)	13236-0059	1
LEVER-COMP (Ref # 13236A)	13236-0060	1
LEVER-COMP (Ref # 13236B)	13236-0071	1
LEVER-COMP (Ref # 13236C)	13236-0072	1
ROD-ASSY-TIE (Ref # 39110)	39110-0018	1
NUT,LEFT HANDED,6MM (Ref # 92015)	92015-1572	1
SPACER (Ref # 92026)	92026-1217	1
SEAL-OIL,VB13193 (Ref # 92049)	92049-1398	2
COLLAR (Ref # 92143)	92143-1595	1
SPRING (Ref # 92144)	92144-1029	1
SPRING (Ref # 92145)	92145-0197	1
SPRING (Ref # 92145A)	92145-0205	1
BOLT,RETURN SPRING (Ref # 92153)	92153-0421	1
BOLT,8X25 (Ref # 92153A)	92153-1268	2
WASHER,20.5X27X1.6 (Ref # 92200)	92200-0018	1
WASHER,13.4X25X1.0 (Ref # 92200A)	92200-0045	1