


2020 MULE 4000 TRANS™ PARTS DIAGRAM

Drive Converter

E1391



2020 MULE 4000 TRANS™ PARTS LIST

Drive Converter

ITEM NAME	PART NUMBER	QUANTITY
GUIDE (Ref # 13070)	13070-1330	6
COVER-ASSY (Ref # 16146)	16146-1219	1
WEIGHT-RAMP (Ref # 39152)	39152-1078	3
SPIDER (Ref # 49050)	49050-0018	1
CONVERTER-ASSY-DRIVE (Ref # 49093)	49093-0025	1
SHEAVE-MOVABLE (Ref # 59301)	59301-0016	1
SHEAVE-COMP (Ref # 59302)	59302-1085	1
NUT,LOCK,6MM (Ref # 92019)	92019-008	6
WASHER,SPECIAL CONICAL (Ref # 92022)	92022-1901	2
SPACER (Ref # 92026)	92026-1512	6
SPACER,32.3X44.3X3.6 (Ref # 92026A)	92026-1591	1
BUSHING (Ref # 92028)	92028-1861	1
BUSHING (Ref # 92028A)	92028-1864	1
PIN (Ref # 92043)	92043-1572	3
PIN (Ref # 92043A)	92043-1573	3
ROLLER (Ref # 92122)	92122-1204	3
SPRING,YELLOW PAINT (Ref # 92145)	92145-0639	1
BOLT,12X163.5 (Ref # 92150)	92150-1008	1
WASHER (Ref # 92200)	92200-1401	1
BOLT-FLANGED,6X30 (Ref # 130)	130CA0630	6