


2019 MULE 4000 TRANS™ PARTS DIAGRAM

Driven Converter/Drive Belt

E1392



2019 MULE 4000 TRANS™ PARTS LIST

Driven Converter/Drive Belt

| ITEM NAME | PART NUMBER | QUANTITY |
|-------------------------------------|-------------|----------|
| SHOE (Ref # 49048) | 49048-1060 | 3 |
| RAMP (Ref # 49092) | 49092-1068 | 1 |
| CONVERTER-ASSY-DRIVEN (Ref # 49094) | 49094-0045 | 1 |
| BELT, CONVERTER (Ref # 59011) | 59011-1077 | 1 |
| SHEAVE-COMP, MOVABLE (Ref # 59302) | 59302-0031 | 1 |
| SHEAVE-COMP (Ref # 59302A) | 59302-0032 | 1 |
| SCREW, SHOE (Ref # 92009) | 92009-1849 | 3 |
| SPACER, 39X50X0.50 (Ref # 92026) | 92026-1507 | AR |
| SPACER, 39X50X0.60 (Ref # 92026A) | 92026-1508 | AR |
| SPACER, 39X50X0.80 (Ref # 92026B) | 92026-1510 | AR |
| SPACER, 34X44X0.80 (Ref # 92026C) | 92026-1521 | 1 |
| SPACER, 39X49.5X1.0 (Ref # 92026D) | 92026-1603 | 1 |
| BUSHING (Ref # 92028) | 92028-1864 | 2 |
| SPRING (Ref # 92145) | 92145-1404 | 1 |
| BOLT, 12X35 (Ref # 92150) | 92150-1009 | 1 |
| CIRCLIP-TYPE-C, 34MM (Ref # 480) | 480J3400 | 1 |