


# 2020 MULE 4000 TRANS™ PARTS DIAGRAM

## Fuel Pump

E1520



## 2020 MULE 4000 TRANS™ PARTS LIST

### Fuel Pump

| ITEM NAME                    | PART NUMBER | QUANTITY |
|------------------------------|-------------|----------|
| PLATE (Ref # 13272)          | 13272-1398  | 1        |
| COVER (Ref # 14092)          | 14092-1044  | 1        |
| RELAY-ASSY (Ref # 27002)     | 27002-1088  | 2        |
| FILTER-FUEL (Ref # 49019)    | 49019-0013  | 1        |
| PUMP-FUEL (Ref # 49040)      | 49040-0718  | 1        |
| TUBE-ASSY,FUEL (Ref # 51044) | 51044-0897  | 1        |
| CHAMBER-FUEL (Ref # 51072)   | 51072-0003  | 1        |
| BOLT,FUEL PUMP (Ref # 92154) | 92154-1326  | 6        |
| CLAMP (Ref # 92171)          | 92171-0453  | 2        |
| CLAMP (Ref # 92171A)         | 92171-0476  | 1        |
| O RING (Ref # 670)           | 670E5090    | 1        |