


# 2005 ZRX1200R

## PARTS DIAGRAM

Frame

F2120



# 2005 ZRX1200R

## PARTS LIST

### Frame

| ITEM NAME                                     | PART NUMBER | QUANTITY |
|---|-------------|----------|
| PIPE-COMP,DOWNTUBE,RH (Ref # 31064)           | 31064-0030  | 1        |
| FRAME-COMP (Ref # 32160A)                     | 32160-0112  | 1        |
| NUT,25MM,T=12 (Ref # 92015)                   | 92015-1546  | 1        |
| NUT,CAP,18MM (Ref # 92015A)                   | 92015-1736  | 1        |
| SEAL-OIL,XMHE36X52X4J (Ref # 92049)           | 92049-1162  | 1        |
| SEAL-OIL,STEERING STEM (Ref # 92049A)         | 92049-1214  | 1        |
| RING-O,ID=24.5 (Ref # 92055)                  | 92055-1459  | 1        |
| BEARING-ROLLER,HR320/28XJ (Ref # 92116)       | 92116-1009  | 1        |
| BEARING-ROLLER,HI-CAP32005JR-1 (Ref # 92116A) | 92116-1056  | 1        |
| BOLT,SOCKET,10X30 (Ref # 92150)               | 92150-1690  | 4        |
| WASHER,19X32X2.6 (Ref # 92200)                | 92200-0100  | 1        |
| WASHER,CLAW,18.5X30X2.3 (Ref # 92200A)        | 92200-1357  | 1        |