


1991 Zephyr PARTS DIAGRAM

Ignition Switch(&NAMI.004498)



1991 Zephyr PARTS LIST

Ignition Switch(&NAMI.004498)

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,SEAT LOCK (Ref # 11046)	11046-1790	1
BRACKET,REFLECTOR,FR (Ref # 11047)	11047-1085	1
BRACKET,REFLECTOR,RR,LH (Ref # 11047A)	11047-1086	1
BRACKET,REFLECTOR,RR,RH (Ref # 11047B)	11047-1087	1
COVER,SIDE STAND SWITCH (Ref # 14024)	14024-1532	1
ROTOR,LOCK,TANK CAP (Ref # 21007)	21007-5027	1
SWITCH-ASSY (Ref # 27004)	27004-5369	1
SWITCH-ASSY-IGNITION (Ref # 27005)	27005-5089	1
KEY-LOCK,BLANK (Ref # 27008)	27008-1103	1
SWITCH,BRAKE LAMP (Ref # 27010)	27010-1093	1
SWITCH,SIDE STAND (Ref # 27010A)	27010-1226	1
LOCK-ASSY,SEAT (Ref # 27016)	27016-5157	1
REFLECTOR-REFLEX (Ref # 28012)	28012-1003	2
REFLECTOR-REFLEX,RR (Ref # 28012A)	28012-1054	2
REFLECTOR-REFLEX (Ref # 28012B)	28012-1077	1
JOINT (Ref # 59071)	59071-1103	1
BOLT,TORX,6X16 (Ref # 92002)	92002-1333	2
NUT,FLANGED,5MM (Ref # 92015)	92015-1259	1
NUT,6MM (Ref # 92015A)	92015-1321	4
SPRING,BRAKE LAMP SWITCH (Ref # 92081)	92081-1704	1
BOLT,SOCKET,5X20 (Ref # 92150)	92150-1019	2
BOLT-FLANGED,6X12 (Ref # 130)	130C0612	2
BOLT-FLANGED,6X14,BLACK (Ref # 130A)	130J0614	4
SCREW-PAN-CROS,6X12 (Ref # 220)	220B0612	2
NUT-HEX (Ref # 311)	311B0500	4
WASHER-PLAIN,6MM (Ref # 411)	411E0600	2
WASHER-SPRING,5MM (Ref # 461)	461F0500	4