


2004 Ninja® ZX™-10R

PARTS DIAGRAM

Air Cleaner

E1130



2004 Ninja® ZX™-10R

PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR (Ref # 11010)	11010-0049	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-0004	1
GASKET (Ref # 11061)	11061-0056	1
CAP,AIR FILTER (Ref # 11065)	11065-0032	1
HOLDER (Ref # 13280)	13280-0062	1
HOLDER (Ref # 13280A)	13280-0063	1
SCREEN (Ref # 14037)	14037-0025	1
FILTER,OIL SEPARATOR (Ref # 14043)	14043-0006	1
DUCT,FUNNEL #1 (Ref # 14073)	14073-0044	2
DUCT,FUNNEL #2 (Ref # 14073A)	14073-0052	2
DUCT,LH (Ref # 14073B)	14073-0067	1
DUCT,RH (Ref # 14073C)	14073-0068	1
HOLDER-ASSY (Ref # 14079)	14079-0005	1
VALVE,AIR CUT (Ref # 16126)	16126-1437	1
DUCT-ASSY,RAM (Ref # 39045)	39045-0010	1
SCREW,TAPPING,5X10 (Ref # 92009)	92009-1499	8
CLAMP,TUBE (Ref # 92037)	92037-147	2
PLUG,DRAIN (Ref # 92066)	92066-1211	1
GROMMET (Ref # 92071)	92071-2140	1
SEAL (Ref # 92093)	92093-0012	1
SEAL (Ref # 92093A)	92093-0026	1
SEAL (Ref # 92093B)	92093-0027	1
SEAL,RAM DUCT (Ref # 92093C)	92093-0029	1
BOLT,6X18 (Ref # 92153)	92153-0756	4
BOLT,6X12 (Ref # 92153A)	92153-0759	5
CLAMP,FUNNEL (Ref # 92171)	92171-0186	2
CLAMP (Ref # 92171A)	92171-0391	2
SCREW,TAPPING,5X20 (Ref # 92172)	92172-0009	7
SCREW (Ref # 92172A)	92172-0056	8

2004 Ninja® ZX™-10R

PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
TUBE,HEAD-ASV (Ref # 92192)	92192-0033	2
TUBE,BREATHER (Ref # 92192A)	92192-0035	1
TUBE,AIR FILTER-ASV (Ref # 92192B)	92192-0096	1
TUBE,7X10X500 (Ref # 92192C)	92192-0156	1
NUT (Ref # 92210)	92210-0130	4