


# 2007 Ninja® ZX™-10R

## PARTS DIAGRAM

### Chassis Electrical Equipment



# 2007 Ninja® ZX™-10R

## PARTS LIST

### Chassis Electrical Equipment

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,6X10 (Ref # 130)	130V0610	2
BRACKET (Ref # 11054)	11054-0043	1
FUSE,15A (Ref # 26006)	26006-0001	4
FUSE,10A (Ref # 26006A)	26006-1078	6
WIRE-LEAD (Ref # 26011)	26011-0037	2
WIRE-LEAD,BATTERY(-) (Ref # 26011A)	26011-0078	1
WIRE-LEAD,BATTERY(+) (Ref # 26011B)	26011-0079	1
BATTERY,YT12B-BS,12V 12AH (Ref # 26012)	26012-0036	1
HARNESS,MAIN (Ref # 26031)	26031-0450	1
RELAY-ASSY (Ref # 27002)	27002-0007	1
RELAY-ASSY,TURN SIGNAL (Ref # 27002A)	27002-1101	1
HORN (Ref # 27003)	27003-0041	1
LABEL,FUSE BOX (Ref # 56030)	56030-0098	1
LABEL,FUSE BOX (Ref # 56030A)	56030-0109	1
CLAMP,HOSE (Ref # 92037)	92037-1827	2
BAND (Ref # 92072)	92072-1414	3
CLAMP (Ref # 92171A)	92171-0305	1
CLAMP,CLIP,DIA=20 (Ref # 92171)	92171-0068	1
CLAMP,CLIP,DIA=20 (Ref # 92171)	92171-0068	2