


# 2005 ZZR1200

## PARTS DIAGRAM

### Transmission

E1361



# 2005 ZZR1200

## PARTS LIST

### Transmission

ITEM NAME	PART NUMBER	QUANTITY
CIRCLIP (Ref # 480)	480J2900	1
BALL-STEEL,5/32" (Ref # 600)	600A0500	3
SHAFT-TRANSMISSION INPUT,15T (Ref # 13127)	13127-1291	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-1255	1
SPROCKET-OUTPUT,17T (Ref # 13144)	13144-1224	1
GEAR,INPUT 2ND,19T (Ref # 13260)	13260-1952	1
GEAR,INPUT 3RD&4TH,22T&24T (Ref # 13260A)	13260-1953	1
GEAR,INPUT 5TH,26T (Ref # 13260B)	13260-1954	1
GEAR,INPUT TOP,28T (Ref # 13260C)	13260-1955	1
GEAR,OUTPUT LOW,41T (Ref # 13260D)	13260-1956	1
GEAR,OUTPUT 2ND,37T (Ref # 13260E)	13260-1957	1
GEAR,OUTPUT 3RD,35T (Ref # 13260F)	13260-1958	1
GEAR,OUTPUT 4TH,32T (Ref # 13260G)	13260-1959	1
GEAR,OUTPUT 5TH,30T (Ref # 13260H)	13260-1960	1
GEAR,OUTPUT TOP,29T (Ref # 13260I)	13260-1961	1
NUT,20MM (Ref # 92015)	92015-1210	1
WASHER,28.3X42X2.9 (Ref # 92022)	92022-1219	1
WASHER,22.3X35X1.6 (Ref # 92022A)	92022-212	2
BUSHING,OUTPUT,3RD&4TH (Ref # 92028)	92028-1753	1
BUSHING,INPUT,TOP GEAR (Ref # 92028A)	92028-1802	1
RING-SNAP,20X25.5X1.2 (Ref # 92033)	92033-025	2
RING-SNAP,T=1.5 (Ref # 92033A)	92033-1249	2
BEARING-BALL (Ref # 92045)	92045-1413	2
BEARING-NEEDLE,FWF-223014 (Ref # 92046)	92046-031	2
RACE,INPUT SHAFT (Ref # 92048)	92048-1052	1
RACE,30X38X15 (Ref # 92048A)	92048-1053	1
COLLAR,SPROCKET (Ref # 92143)	92143-1649	1
WASHER,TOOTHED,23.9X45X1.0 (Ref # 92200)	92200-1234	1
WASHER,TOOTHED,28X30X2 (Ref # 92200A)	92200-1277	1

# 2005 ZZR1200

## PARTS LIST

### Transmission

ITEM NAME	PART NUMBER	QUANTITY
WASHER,29.9X40X1.5 (Ref # 92200B)	92200-1278	1
WASHER (Ref # 92200C)	92200-1340	2