


1992 Ninja[®] ZX[™]-6

PARTS DIAGRAM

Rear Hub



1992 Ninja[®] ZX[™]-6

PARTS LIST

Rear Hub

ITEM NAME	PART NUMBER	QUANTITY
AXLE,RR (Ref # 41068)	41068-1314	1
WHEEL-ASSY,RR,G.GRAY (Ref # 41073A)	41073-1484-HY	1
COUPLING-ASSY,RR HUB,G.GRAY (Ref # 42033)	42033-1142-GD	1
SLEEVE,RR AXLE,L=22 (Ref # 42036)	42036-1233	1
SPROCKET-HUB,45T (Ref # 42041)	42041-1361	1
NUT,CASTLE,16MM (Ref # 42045)	42045-014	1
WASHER,17.3X32X3.2 (Ref # 42046)	42046-009	1
STUD,10X19.5 (Ref # 92004)	92004-1151	6
NUT,10MM (Ref # 92015)	92015-1720	6
RING-SNAP,47MM (Ref # 92033)	92033-1042	1
RING-SNAP,52MM (Ref # 92033A)	92033-1043	1
SEAL-OIL,BJN28475 (Ref # 92049)	92049-1056	1
SEAL-OIL,TWC35527 (Ref # 92052)	92052-006	1
CHAIN,DRIVE,EK50MV-OX110L (Ref # 92057)	92057-1221	1
COLLAR,RR AXLE,L=14.5 (Ref # 92143)	92143-1209	1
COLLAR,RR AXLE,L=26 (Ref # 92143A)	92143-1210	1
COLLAR,RR HUB,L=125 (Ref # 92143B)	92143-1393	1
DAMPER,SHOCK,RR HUB (Ref # 92160)	92160-1248	1
PIN-COTTER,4.0X35 (Ref # 550)	550D4035	1
BEARING-BALL,#6205G (Ref # 601)	601B6205G	1
BEARING-BALL,#6303ZZC3 (Ref # 601A)	601B6303ZZ	2