


# 2000 Ninja® ZX™-6 PARTS DIAGRAM

Clutch



## 2000 Ninja® ZX™-6 PARTS LIST

### Clutch

ITEM NAME	PART NUMBER	QUANTITY
HUB-CLUTCH (Ref # 13087)	13087-042	1
PLATE-FRICTION (Ref # 13088)	13088-1087	7
PLATE-CLUTCH,T=2.3 (Ref # 13089)	13089-1004	6
HOLDER,CLUTCH SPRING (Ref # 13091)	13091-1840	5
HOUSING-COMP-CLUTCH (Ref # 13095)	13095-1304	1
RELEASE-COMP-CLUTCH (Ref # 13102)	13102-1123	1
PLATE-CLUTCH OPERATING (Ref # 13187)	13187-1006	1
ROD,CLUTCH (Ref # 46102)	46102-1030	1
NUT,20MM (Ref # 92015)	92015-1555	1
WASHER (Ref # 92022)	92022-1868	1
SPACER,25X66X2.0 (Ref # 92026)	92026-1383	2
SPACER,25.5X38X1.0 (Ref # 92026A)	92026-1536	1
BEARING-BALL,6001C3ML01 (Ref # 92045)	92045-1235	1
COLLAR (Ref # 92143)	92143-1387	1
SPRING,CLUTCH (Ref # 92144)	92144-1731	5
BOLT,SOCKET,6X35 (Ref # 92150)	92150-1713	5