



# 2001 Ninja® ZX™-6 PARTS DIAGRAM

Front Wheel

F2230



## 2001 Ninja® ZX™-6 PARTS LIST

### Front Wheel

| ITEM NAME                            | PART NUMBER   | QUANTITY |
|--------------------------------------|---------------|----------|
| BEARING-BALL,#6004UUC3 (Ref # 601)   | 601B6004UU    | 2        |
| GEAR-METER SCREW,9T (Ref # 41060)    | 41060-1123    | 1        |
| GEAR-METER SCREW,23T (Ref # 41060A)  | 41060-1138    | 1        |
| WASHER,5.1X9X0.4 (Ref # 41063)       | 41063-001     | 2        |
| RECEIVER-SPEEDOMETER (Ref # 41064)   | 41064-1006    | 1        |
| AXLE,FR (Ref # 41068)                | 41068-1311    | 1        |
| WHEEL-ASSY,FR,G.GRAY (Ref # 41073)   | 41073-1518-GE | 1        |
| CASE-ASSY-METER GEAR (Ref # 41078)   | 41078-1076    | 1        |
| PIN,SPRING (Ref # 41082)             | 41082-001     | 1        |
| BUSHING,SPEEDOMETER (Ref # 92028)    | 92028-1066    | 1        |
| RING-SNAP,42MM (Ref # 92033)         | 92033-1041    | 2        |
| SEAL-OIL,BJN30427-C3 (Ref # 92049)   | 92049-1057    | 2        |
| COLLAR,FR AXLE,L=43.5 (Ref # 92143)  | 92143-1301    | 1        |
| COLLAR,FR AXLE,L=25.5 (Ref # 92143A) | 92143-1359    | 1        |
| COLLAR,FR HUB,L=86.5 (Ref # 92143B)  | 92143-1479    | 1        |