


1996 Ninja® ZX™-6R

PARTS DIAGRAM

Cowling Lower(ZX600-F2)



1996 Ninja® ZX™-6R

PARTS LIST

Cowling Lowers(ZX600-F2)

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,LWR COWLING,UPP (Ref # 11048)	11048-1868	1
BRACKET,LWR COWLING,LH,LWR (Ref # 11048A)	11048-1869	1
BRACKET,LWR COWLING,RH,LWR (Ref # 11048B)	11048-1870	1
BRACKET,RESERVOIR TANK (Ref # 11049)	11049-1274	1
DUCT,AIR,LH (Ref # 14073)	14073-1631	1
DUCT,AIR,RH (Ref # 14073A)	14073-1632	1
COVER,LWR COWLING,RH (Ref # 14090)	14090-1602	1
PAD,LWR COWLING,LH,UPP (Ref # 39156)	39156-1437	1
PAD,LWR COWLING,LH,LWR (Ref # 39156A)	39156-1438	1
PAD,LWR COWLING,RH,FR (Ref # 39156B)	39156-1439	1
PAD,LWR COWLING,RH,RR (Ref # 39156C)	39156-1440	1
COWLING,LWR,LH,F.RED (Ref # 55028)	55028-1331-B1	1
COWLING,LWR,RH,F.RED (Ref # 55028A)	55028-1332-B1	1
COWLING,LWR,FR,F.RED (Ref # 55028B)	55028-1333-B1	1
COWLING,LWR,FR,L.GREEN (Ref # 55028C)	55028-1333-7F	1
COWLING.,LWR,LH,L.GREEN (Ref # 55049)	55049-5465-7F	1
COWLING.,LWR,RH,L.GREEN (Ref # 55049A)	55049-5466-7F	1
SCREW,TAPPING,5X10 (Ref # 92009)	92009-1332	10
SCREW,5X16 (Ref # 92009A)	92009-1654	2
SCREW,5X20 (Ref # 92009B)	92009-1656	2
SCREW,5X25 (Ref # 92009C)	92009-1657	4
NUT,WELL,5MM (Ref # 92015)	92015-1757	6
NUT,5MM (Ref # 92015A)	92015-1798	2
WASHER,NYLON,5.3X11.5X1.5 (Ref # 92022)	92022-1521	6
BOLT-FLANGED,6X10 (Ref # 130)	130V0610	2
BOLT-FLANGED,6X14 (Ref # 130A)	130V0614	4
DAMPER (Ref # 92075)	92075-1067	4
DAMPER (Ref # 92075A)	92075-1634	6
COLLAR,BLACK (Ref # 92143)	92143-1226	6

1996 Ninja® ZX™-6R

PARTS LIST

Cowling Lowers(ZX600-F2)

ITEM NAME	PART NUMBER	QUANTITY
BOLT,SOCKET,6X18 (Ref # 92150)	92150-1553	4
BOLT,SOCKET,6X30 (Ref # 92150A)	92150-1554	2
DAMPER (Ref # 92160)	92160-1632	1
CLAMP (Ref # 92170)	92170-1230	1
CLAMP (Ref # 92170A)	92170-1442	2