


2003 Ninja® ZX™-6RR PARTS DIAGRAM

Fuel Tank

F2410



2003 Ninja® ZX™-6RR PARTS LIST

Fuel Tank

ITEM NAME	PART NUMBER	QUANTITY
BOLT-SOCKET (Ref # 120)	120S0516	3
BOLT-FLANGED,6X70,BLACK (Ref # 130)	130J0670	1
TUBE-RUBBER,6X850 (Ref # 702)	702A06850	1
BRACKET-TANK,FR (Ref # 32052)	32052-1572	1
PAD,FUEL TANK,CNT (Ref # 39156)	39156-0015	1
PAD,FUEL TANK,LH (Ref # 39156A)	39156-0016	1
PAD,FUEL TANK,RH (Ref # 39156B)	39156-0017	1
CAP-TANK,FUEL (Ref # 51049)	51049-1127	1
BOLT,6X20 (Ref # 92002)	92002-1237	2
COLLAR,L=13.1 (Ref # 92027)	92027-251	2
CLAMP,TUBE (Ref # 92037)	92037-010	1
COLLAR,6.8X10X60 (Ref # 92152)	92152-1182	1
BOLT,SOCKET,8X16 (Ref # 92153)	92153-0327	1
DAMPER (Ref # 92160)	92160-1162	2
DAMPER,FUEL TANK (Ref # 92161)	92161-0057	2
DAMPER (Ref # 92161A)	92161-0066	2
DAMPER,FUEL TANK,RR (Ref # 92161B)	92161-1330	2
TANK-COMP-FUEL,L.GREEN (Ref # 51083)	51083-5001-7F	1
TANK-COMP-FUEL,L.GREEN (Ref # 51083I)	51083-5012-7F	1
SEAL,FUEL TANK CAP (Ref # 92093)	92093-1030	1