

2005 Ninja® ZX™-6RR

PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
O RING (Ref # 670)	670D1505	3
PLATE,BREATHER (Ref # 13271)	13271-0380	1
PLATE,SIDE BREATHER (Ref # 13271A)	13271-0381	1
SET-CRANKCASE (Ref # 14001)	14001-0053	1
RING-POSITION (Ref # 14013)	14013-004	2
PLATE-POSITION (Ref # 14014)	14014-0017	1
SENSOR,SPEED (Ref # 21176)	21176-0028	1
SWITCH,OIL PRESSURE (Ref # 27010)	27010-1313	1
PIPE-OIL (Ref # 39193)	39193-0025	1
PIPE-OIL (Ref # 39193A)	39193-0026	1
BOLT,6X10 (Ref # 92002)	92002-1449	2
BOLT,SOCKET,6X16 (Ref # 92002A)	92002-1778	2
BOLT,SOCKET,6X12 (Ref # 92002B)	92002-1796	2
FITTING,BREATHER (Ref # 92005)	92005-1238	1
SPACER,14.3X16.6X3.2 (Ref # 92026)	92026-0069	2
PIN,DOWEL,6.3X8X14 (Ref # 92042)	92042-007	2
PIN (Ref # 92043)	92043-1506	3
PIN,6X16 (Ref # 92043A)	92043-1690	2
BEARING-NEEDLE,7E-HK1412 (Ref # 92046)	92046-037	1
SEAL-OIL,TC32528 (Ref # 92049)	92049-1307	1
SEAL-OIL,TC14245 (Ref # 92049A)	92049-1520	1
RING-O,13.8X1.9 (Ref # 92055)	92055-0065	2
RING-O (Ref # 92055A)	92055-1146	1
RING-O,5.5X1.5 (Ref # 92055B)	92055-1343	2
NOZZLE,OIL JET (Ref # 92062)	92062-0006	2
PLUG,OIL LINE,7.2X8 (Ref # 92066)	92066-1012	1
PLUG (Ref # 92066A)	92066-1110	2
PLUG,PT3/8X12 (Ref # 92066B)	92066-1252	1
PLUG,MAIN GALLERY,18X9 (Ref # 92066C)	92066-1394	1

2005 Ninja® ZX™-6RR

PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
BOLT,SOCKET,5X20 (Ref # 92150)	92150-1019	2
BOLT,6X12 (Ref # 92150A)	92150-1841	1
BOLT,6X16 (Ref # 92151)	92151-1774	1
BOLT,8X15 (Ref # 92153)	92153-0753	2
CLAMP (Ref # 92170)	92170-1167	1
CLAMP (Ref # 92170A)	92170-1925	1
CLAMP,WATER HOSE (Ref # 92171)	92171-0473	1
TUBE,BREATHER (Ref # 92192)	92192-0155	1