

Air Cleaner

Exploded view diagram of a vehicle's front suspension assembly. The diagram shows the following components and their assembly order:

- 11010**: Upper control arm assembly.
- 11011**: Upper control arm bushing.
- 92093**: Upper control arm bushing.
- 11029**: Upper control arm bushing.
- 92171**: Upper control arm bushing.
- 130**: Upper control arm bushing.
- 92143**: Upper control arm bushing.
- 92171A**: Upper control arm bushing.
- 49006**: Upper control arm bushing.
- 92171B**: Upper control arm bushing.
- 14073**: Upper control arm bushing.
- 12026**: Upper control arm bushing.
- 92161B**: Upper control arm bushing.
- 92161A**: Upper control arm bushing.
- 92161**: Upper control arm bushing.
- 92161C**: Upper control arm bushing.
- 92192**: Upper control arm bushing.
- 92171A**: Upper control arm bushing.
- 49006**: Upper control arm bushing.
- 92170**: Upper control arm bushing.
- 14073A**: Upper control arm bushing.
- 92037**: Upper control arm bushing.
- 92170A**: Upper control arm bushing.
- 14073C**: Upper control arm bushing.
- 92170A**: Upper control arm bushing.
- 14073B**: Upper control arm bushing.
- Ref. Frame**: Reference frame.
- 130**: Upper control arm bushing.
- 92143**: Upper control arm bushing.
- 92171**: Upper control arm bushing.
- 92171A**: Upper control arm bushing.
- 49006**: Upper control arm bushing.
- 92171B**: Upper control arm bushing.
- 14073**: Upper control arm bushing.
- 12026**: Upper control arm bushing.
- 92161B**: Upper control arm bushing.
- 92161A**: Upper control arm bushing.
- 92161**: Upper control arm bushing.
- 92161C**: Upper control arm bushing.
- 92192**: Upper control arm bushing.
- 92171A**: Upper control arm bushing.
- 49006**: Upper control arm bushing.
- 92170**: Upper control arm bushing.
- 14073A**: Upper control arm bushing.
- 92037**: Upper control arm bushing.
- 92170A**: Upper control arm bushing.
- 14073C**: Upper control arm bushing.
- 92170A**: Upper control arm bushing.
- 14073B**: Upper control arm bushing.
- Ref. Frame**: Reference frame.

2021 TERYX4™ PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR (Ref # 11010)	11010-0777	1
CASE-AIR FILTER (Ref # 11011)	11011-0784	1
ELEMENT-ASSY-AIR FILTER (Ref # 11029)	11029-0025	1
CHAMBER (Ref # 12026)	12026-0016	1
DUCT,JOINT,A/C SIDE (Ref # 14073)	14073-0757	1
DUCT,THROTTLE-CHAMBER (Ref # 14073A)	14073-0758	2
DUCT,INTAKE (Ref # 14073B)	14073-0767	1
DUCT,JOINT (Ref # 14073C)	14073-1775	1
BOOT (Ref # 49006)	49006-1351	2
CLAMP (Ref # 92037)	92037-1523	2
SEAL (Ref # 92093)	92093-0585	1
COLLAR (Ref # 92143)	92143-1087	4
DAMPER,CHAMBER,RH,RR (Ref # 92161)	92161-1518	1
DAMPER,CHAMBER,RH,FR (Ref # 92161A)	92161-1519	1
DAMPER,CHAMBER,LH,RR (Ref # 92161B)	92161-1520	1
DAMPER,CHAMBER,LH,FR (Ref # 92161C)	92161-1521	1
CLAMP (Ref # 92170)	92170-1676	2
CLAMP (Ref # 92170A)	92170-1764	2
CLAMP (Ref # 92171)	92171-0225	6
CLAMP (Ref # 92171A)	92171-1277	2
CLAMP (Ref # 92171B)	92171-3716	2
TUBE,4X8X143 (Ref # 92192)	92192-1230	1
BOLT-FLANGED,6X16 (Ref # 130)	130AA0616	4