

2006 Ninja[®] ZX[™]-6R


PARTS DIAGRAM

Front Wheel

Kawasaki

Let the Good Times Roll[®]

F2230



2006 Ninja® ZX™-6R

PARTS LIST

Front Wheel

| ITEM NAME | PART NUMBER | QUANTITY |
|--|----------------|----------|
| BEARING-BALL,#6005UU (Ref # 601) | 601B6005UU | 2 |
| AXLE,FR (Ref # 41068) | 41068-0034 | 1 |
| WHEEL-ASSY,FR,C.P.RED (Ref # 41073) | 41073-0039-10I | 1 |
| SEAL-OIL,BJN 32 47 5 (Ref # 92049) | 92049-1377 | 2 |
| COLLAR,FR AXLE,LH,L=44.5 (Ref # 92152) | 92152-0240 | 1 |
| COLLAR,FR HUB,L=115 (Ref # 92152A) | 92152-0242 | 1 |
| COLLAR,FR AXLE,L=13 (Ref # 92152B) | 92152-0289 | 2 |