


2025 KX™250 PARTS DIAGRAM

Crankcase



2025 KX™250 PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
VALVE-REED (Ref # 12022)	12022-0010	1
PLATE (Ref # 13272)	13272-0488	4
PLATE (Ref # 13272A)	13272-0670	2
SET-CRANKCASE (Ref # 14101)	14101-0046	1
STOPPER,VALVE-REED (Ref # 32085)	32085-0876	1
FITTING (Ref # 92005)	92005-1369	1
SPACER (Ref # 92026)	92026-0979	1
CLAMP,TUBE (Ref # 92037)	92037-1972	1
PIN,PLUNGER (Ref # 92043)	92043-1676	1
PIN,10.1X12X14 (Ref # 92043A)	92043-4009	2
BEARING-BALL,6202SH2C3 (Ref # 92045)	92045-0037	1
BEARING-BALL,22X50X14 (Ref # 92045A)	92045-0051	1
BEARING-BALL,CRANKSHAFT MAIN (Ref # 92045B)	92045-0827	2
BEARING-BALL,TMB203LU (Ref # 92045C)	92045-1287	2
BEARING-BALL,SX04A81C3 (Ref # 92045D)	92045-1335	1
BEARING-BALL,6805JRZ (Ref # 92045E)	92045-1432	1
BEARING-BALL,6203 (Ref # 92045F)	92045-1465	1
BEARING-NEEDLE,7E-HKS33X38X8 (Ref # 92046)	92046-1221	1
SEAL-OIL,TC 30 40 7 (Ref # 92049)	92049-0030	3
SEAL-OIL (Ref # 92049A)	92049-0808	1
SEAL-OIL,TB13225.5 (Ref # 92051)	92051-005	1
NOZZLE (Ref # 92062)	92062-0029	1
NOZZLE (Ref # 92062A)	92062-0576	2
GASKET,8.5X16X1 (Ref # 92065)	92065-023	1
BUSHING (Ref # 92139)	92139-0907	1
SPRING (Ref # 92145)	92145-0453	1
COLLAR (Ref # 92152)	92152-2453	1
BOLT,TORX (Ref # 92154)	92154-1621	6
BOLT,FLANGED,6X65 (Ref # 92154A)	92154-1929	3

2025 KX™ 250 PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
BOLT,FLANGED,6X14 (Ref # 92154B)	92154-2964	1
BOLT,FLANGED,6X70 (Ref # 92154C)	92154-2981	2
BOLT,FLANGED,6X60 (Ref # 92154D)	92154-4134	9
CLAMP (Ref # 92171)	92171-0761	1
CLAMP (Ref # 92173)	92173-2551	1
TUBE,BREATHER (Ref # 92192)	92192-1886	1
BOLT-FLANGED,8X16 (Ref # 130)	130AA0816	1